




# CONTROL PANEL PARTS

For Model: RB760PXYB4, RB760PXYQ4  
(BLACK) (DESIGNER WHITE)

27" BUILT-IN ELECTRIC  
SINGLE SELF CLEAN OVEN



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		End Cap
	3183630	Left Hand
	3183631	Right Hand
2	3184641	Trim, Top
	3185383	Screw (2)
3		Trim, Center
	3183573	Black Model
	3183575	White Model
4		Door, Vent
	3183501	Black Model
	3183503	White Model
5		End Trim
		(Vent Door)
		Left Hand
	3148697	Black Model
	3148471	White Model
		Right Hand
	3148698	Black Model
	3148472	White Model
6		Trim, Bottom
	3184408	Black Model
	3184409	White Model
	342043	Screw (2)
7		Control Panel
	3184648	Black Model
	3184649	White Model
8	3183492	Stiffner, Bracket
	254217	Screw
9		Trim, Vent Upper
	3184589	Black Model
	3184588	White Model
11		Electronic Timer
	3182391	Black Model
	3182392	White Model
	3148443	Screw
12	3179916	Insert, Vent
13	3181279	Bracket, Vent
		Insert
	3148443	Screw
14		Switch, Rocker
	3182717	Black Model
	3182718	White model
15	3183493	Stiffner, Bracket
	4159465	Screw


### FOLLOWING PARTS NOT ILLUSTRATED

LIT885533	Repair Parts List
LIT3184643	Tech Sheet
LIT3183636	Installation
	Instructions
LIT3182871	Use & Care Guide
LIT3181454	Brochure

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Model: RB760PXYB4, RB760PXYQ4  
(BLACK) (DESIGNER WHITE)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			8	3185438	Plate, Latch Strike	14	3179498	Glass, Door Black
1	3185497	Liner, Door	9	3185439	Retainer, Glass		3179500	White
2	3185462	Gasket, Window		3148443	Screw		3148443	Screw
3	3185457	Glass, Clear	10	3185459	Glass, Clear	15	3185472	Foil, Adhesive
4	3185460	Insulation, Door	11	3148282	Clip, Mounting		4159465	Screw
5	3185437	Insulation Retainer		3178001	Screw, Black (2)	16	3185525	Trim, Door Black Model
	4173601	Screw	12	3180607	Frame, Door		3185527	White Model
7	3185458	Glass, Reflective	13		Handle, Door	17	3181701	Bumper, Door Glass
				3179481	Black Model	18	3181364	Cap, Top (White Model Only)
				3179483	White Model			
				355515	Screw			
				4173601	Screw, Black			
				4170323	Screw, Chrome			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Model: RB760PXYB4, RB760PXYQ4  
(BLACK) (DESIGNER WHITE)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Model: RB760PXYB4, RB760PXYQ4  
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			16	3179848	Clip, Oven Seal	33	3179587	Retainer, Seal
3	3177625	Cabinet, Back	17	3177681	Bracket, Switch		3179776	Screw (2)
	3148443	Screw	18	3177923	Insulator, Switch	34		Vent, Lower Trim
6	3178142	Cabinet, Top	19	3177621	Bottom, Module		3177783	Black Model
	3148443	Screw	20	3179220	Rail, Support (2)		3177789	Brushed Chrome
7	3183748	Top, Module		3148443	Screw		3180022	Screw, Black
	3148443	Screw	22	3177434	Support, Oven		3179847	Screw, Zinc
8	3177442	Side, Cabinet	23	3178612	Shield, Radiation	36	3149653	Thermostat
		Left & Right Side	24	3177433	Bracket, Hinge	37	4168203	Cover, Cap Tube
	3148443	Screw		3179795	Screw (6)		4159445	Screw
9	3181699	Tube, Vent	26	3177560	Back, Module	38	3179922	Tube, Vent (Female)
	3185383	Screw (3)	27	3185562	Liner, Oven		4173231	Screw
10	3150505	Oven Light Assy.	28	3178298	Hinge, Door (2)	39	3184652	Tube, Vent (Male)
11	3184533	Gasket, Light		3179795	Screw (4)		3148443	Screw
12	311255	Bulb, Oven Light	29	3185085	Button, Plug	43	3177551	Bottom, Oven
14	3177689	Frame, Front	30	3182814	Button, Plug	45	3177545	Bracket, Conduit Mounting
15	3179813	Seal, Door		3148443	Screw	46	3185551	Insulation, Oven
	3179776	Screw (4)	31	4173553	Switch, Door	47	3177872	Insulation, Back
				4159117	Nut (2)	48	3183752	Bracket, Mounting Control Panel
				313489	Screw (2)			

## UNIT PARTS



Illus. Part No. No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.



1	3185562	Liner, Oven
2	660579	Element, Broil
	3185383	Screw (4)
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
5	3185307	Rack, Offset
6	3185308	Rack, Oven
7	661416	Element, Bake
	3185383	Screw (2)
8	3182950	Bracket, Element (2)
	3179117	Screw
9	3148440	Sensor, Oven

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COMPONENT SHELF AND LATCH PARTS

For Model: RB760PXYB4, RB760PXYQ4

(BLACK) (DESIGNER WHITE)



**Illus. Part No. No. DESCRIPTION**


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	3184592	Shelf, Component
	3148443	Screw
2	3184673	Block, Terminal
	308043	Screw
3	4159035	Bushing
4	3178671	Switch, Latch
	98106	Screw (2)
5	3178185	Insulator, Switch
6	3177662	Guard, Latch
7	3177969	Handle, Latch
8	3184039	Knob, Latch
		Handle
	3183294	Screw
9	3184041	Spacer, Latch
		Handle (2)
	3184042	Screw (2)
10	3178410	Latch Mechanism
11	3177496	Plate, Mounting
	3177991	Screw
12	3179777	Button, Plug
13	3178132	Extension, Shelf
	3177991	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WIRING HARNESS PARTS

For Model: RB760PXYB4, RB760PXYQ4  
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
1	3184705	Wiring Harness Door Switch
4	3184706	Wiring Harness (Oven)
6	3179668	Standoff, Wire
	3148443	Screw
8	357572	Clip
	112432	Nut, Hex (3)
9	3184691	Wiring Harness (Latch Assembly)
10	3179669	Clamp (Small)
	3148107	Screw
11	255564	Clamp (Large)
	3148107	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Model: RB760PXYB4, RB760PXYQ4

(BLACK) (DESIGNER WHITE)

Illus. Part No. No.	DESCRIPTION
------------------------	-------------

**FOLLOWING PARTS  
NOT ILLUSTRATED**

**SPLICING WIRES--25FT.**

**LENGTH**

350806	Yellow 16 Ga. 80°c Rating
242829	Blue 14 Ga. 150°c Rating
242820	Black
242821	Blue
242822	Brown
242823	Green
242824	Orange
242825	Red
242826	White
242827	Yellow 14 Ga. 200°c Rating
242830	Brown
242831	Red
242832	Yellow 12 Ga. 150°c Rating
242828	Black
242829	Red

Illus. Part No. No.	DESCRIPTION
------------------------	-------------

**PAINT, TOUCH-UP (1/2oz.)**

72017	White
72107	Almond
72110	Harvest Gold
72112	Toast
72113	Platinum
72032	Black
261869	Citrine White

**PAINT, PRESSURIZED SPRAY  
(13 oz.)**

350930	White
350956	Almond
261890	Harvest Gold
285365	Toast
285366	Platinum
830864	Black
350942	Primer
350941	Leveler (Primer)

Illus. Part No. No.	DESCRIPTION
------------------------	-------------

**PAINT, BULK (1 qt.)**

799344	White
978883	Almond
261891	Harvest Gold
285367	Toast
285368	Platinum

**ADHESIVE**

482338	Sealer, Silastic (3 Oz.)
591014	Adhesive, Loctite (1/3 Oz.)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST