




29" GAS DRYER

MODELS:

WGD7300DW0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4	W10123956	Panel, Dampening	13	8533971	Screw
	W10680136	Installation Instructions	5	W10634454	Harness, User Interface	14	8312709	Clip, Console
	W10680128	Guide, Use and Care	6	3348629	Screw	15	W10686798	Cover, Terminal Block
	W10680138	Tech Sheet	7	W10298336	Nut, "U"	16	W10631629	Console Mount (Right)
	W10743379	Quickstart Guide	8	W10726632	Seal, Console	17	W10631630	Console Mount (Left)
2		Console Assembly (Complete)	9	W10775189	Panel, Rear	18		Lint Screen
	W10622070	White	10	W10219342	Screw		W10508973	White
3	W10607498	Wiring Harness	11	W10691551	Control, Electronic	19	W10662472	Collar, Lint Chute
			12		Top	20	W10507955	Assembly, Fascia
				W10613389	White	21	W10568405	Assembly, Speaker


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8533974	Screw	16	98234	Clip, Ground	31	344020	Cord, Power
2	3390631	Screw	17	8066092	Lock, Front Top	32	W10775448	Clip, Front Panel
3	693995	Screw	18		Panel, Front	33	W10641296	Hinge, Top
4	W10236073	Bracket, Cabinet		W10664698	White	34	691366	Idler Assembly
5	3396795	Cover, Terminal Block	19	685203	Clip, Felt Pad	35	W10709670	Belt, Drive
6	3404162	Clamp, Motor (With Shield)	20	W10610880	Assembly, Door Catch	36	348780	Base, Motor
7	W10634729	Panel, Rear	21	W10730752	Seal, Door	37	3400500	Bolt
8		Badge	22	343641	Screw	38	8066184	Pulley, Motor
	W10387117	White	23	W10727507	Clamp, Pipe	39	W10396029	Assembly, Motor
9	W10569603	Switch, Door	24	W10362431	Assembly, Hinge and Pin	40	W10121316	Clamp, Motor Mount
10	697773	Screw	25	3403431	Strike, Door	41	W10336852	Burner Assembly (60 Hz) (Type 1 and 2)
11	342055	Screw	26	W10463967	Door, Inner	42	W10641295	Bracket, Rear
12	W10567345	Plug, Strike	27		Door, Outer	43	W10529197	Bezel, Door Catch
13	3392100	Foot, Dryer		3402335	White	44	W10529198	Cover, Door Catch
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	28		Handle, Door	45	688983	Screw
				W10549553	White	46	W10685675	Seal, Rear Panel
14	3404413	Plug, Hole (White)	29	W10663510	Assembly, Seal and Bearing			
15		Cabinet	30		Plug, Front Panel			
	8530603	White		8564457	White			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	348368	Assembly, Lint Chute	17	3390647	Screw	32	3402841	Lens, Drum Light
2	489463	Screw	18	8066049	Funnel, Burner Light	33	692526	Bearing, Ring
3	3388703	Washer	19	W10214261	Socket, Light	34	W10219342	Screw
4	347139	Seal, Lint Chute	20	3406124	Bulb, Light	35	W10725245	Seal, Rear Drum
5	90767	Screw	21	3977373	Bracket, Drum Light	36	W10757750	Assembly, Drum (Complete)
6	W10389567	Shield, Exhaust	22	3406022	Bracket, Bulkhead Chute	37	692490	Baffle, Drum (Long)
7	3392519	Fuse, Thermal (91C)	23	339956	Seal	38	3976434	Bracket, Support
8	W10681051	Pad, Sensor	24	W10512946	Washer, Tri Ring	39	90296	Nut, Push On
9	8577274	Thermistor	25	W10359270	Shaft, Drum Roller - Left Hand Thread	40	3403636	Baffle, Drum (Short)
10	694089	Wheel, Blower	26	W10359269	Shaft, Drum Roller - Right Hand Thread	41	W10709380	Seal, Drum Light
11	8577230	Housing, Blower	27	3397590	Roller, Support	42	W10044579	Washer, Nozzle
12	3398161	Clip, Heater Box	28	348197	Washer	43	W10044628	Nut, Brass
13	3390631	Screw	29	W10298789	Nut, Hex	44	W10562804	Valve and Hose Assembly
14	8530285	Box, Heater (96C)	30	W10714471	Bulkhead			
15	W10423382	Thermostat, High Limit SPST (180F)	31	338906	Sensor, Radiant			
16	W10480709	Kit, Thermal Cut-Off (Includes Thermostat)						

BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10336852	Burner Assembly (60 Hz) (Type 1 and 2)	7	693986	Base, Burner	13	326049536	Screw
2	688617	Tube, Burner	8	3387057	Screw			Following Parts Not Illustrated
3	694298	Bracket, Ignitor	9	234826	Orifice, Burner Type 1 (Natural)	49572A		Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
4	686590	Ignitor	10	W10622159	Valve, Gas			
5	W10366705	Screw	11	W10295523	Pipe Plug			
6	343641	Screw	12	W10328463	Coil (60 Hz)			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	279948	Kit, Dryer Repair
	346764	Kit, Hold Down
	8522199	Kit, Dryer Vent Testing
	W10322470A	Dry Rack
	W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
	W10439655	Hose, Inlet (2')
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10242307	Washer, Hose

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)