




ELECTRIC DRYER

MODELS:

MED8630HW1 (White)

MED8630HC1 (Chrome Shadow)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2		Top	8	W10920818	Jumper, Harness HMI (Board to Board)
	W11204389	Use and Care Guide		W10208383	White			
	W11184899	Tech Sheet		W10460919	Chrome Shadow	9		Assembly, Console
	W11183136	Installation Instructions	3	3390647	Screw		W11314475	White
	W11241396	Wiring Diagram	4	W11255768	Channel, Water		W11314480	Chrome Shadow
	W11184894	Quick Start Guide	5	12990702	Screw	10	W11036819	Harness, WiFi
			6	W10208198	Bracket, Console	11	W11157867	Harness, Wiring (Main)
			7	W11123730	Assembly, WIFI			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)	14		Panel, Side	23	W10547287	Assembly, Idler
				W11177568	White	24	W10468057	Assembly, Pulley
				W11177570	Chrome Shadow	25	W10512946	Washer, Tri Ring
2	279393	Screw Kit, Terminal Block	15	W10504381	Pad, Foam	26	W10446781	Spring, Idler
			16		Panel, Front	27	3387610	Belt, Drive
				W10651060	White	28	W10121316	Clamp, Motor Mount
3	3397659	Block, Terminal		W10637127	Chrome Shadow	29	W10806758	Assembly, Motor
4	489463	Screw		W10208250	Strike, Door	30	8066184	Pulley, Motor
5	W10316167	Cover, Terminal Block	17	W10288126	Screw	31	W10242878	Bracket, Motor Mounting
6	3390647	Screw	18	3357011	Screw			
7	W10208382	Bracket, Rear	19	3387242	Seal, Front Panel	32	343641	Screw
8	W10487430	Panel, Rear	20			33	W10639171	Badge, Maytag
9	W10773242	Screw	21	W10569114	Door Switch, Snap In			DRYER EXHAUST KIT NOT INCLUDED
10	3393008	Screw	22	3392100	Foot, Dryer			
11	3389420	Screw		279810	Foot, Optional (Extended Length Package Of 2) (Not Included)		W10323246	Kit, 4-Way Vent
12	8565046	Base, Cabinet						
13	W11382260	Appliance Control Unit (ACU)						


BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11104018	Assembly, Air Duct	17	W11100488	Nozzle, Cap	33	8577274	Thermistor
2	3390647	Screw	18	W11157054	Valve and Hose Assembly	34	W10344699	Collar, Duct
3	W11209934	Bulkhead				35	W10342188	Exhaust Pipe
4	W10001120	Nut, Hex (Left Hand Thread)	19	W10672683	Assembly, Outlet Grill and Housing	36	W10891205	Assembly, Weld Heater Box
5	3387459	Washer	20	W10298258	Harness, Sensor	37	280148	Kit, Thermal Cut-Off (Includes Thermostat)
6	W10512946	Washer, Tri Ring	21	3387223	Sensor, Electrode	38	8557403	Thermostat, High Limit
7	W10359272	Shaft, Drum Roller - Left Hand Thread	22		Lint Screen	39	8066099	Bracket, Heater Box
8	W10314171	Roller, Support		W10516085	White	40	W11045584	Element, Heater
9	W10359271	Shaft, Drum Roller - Right Hand Thread	23	W10673491	Bulkhead, Front	41	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
10	3934666	Nut, Hex	24	W10211950	Seal, Housing Outlet			
11	W10541657	Assembly, Drum (Complete)	25	W11257251	Shield, Blower	42	W10653662	Pad, Foam
12	W10280771	Baffle, Drum	26	W10211896	Assembly, Lint Duct	43	W11203983	Assembly, Drum Light
13	W10219342	Screw	27	W10414388	Clip, Lint Duct	44	W10794806	Screw
14	W10521122	Seal, Drum Front	28	W11254843	Assembly, Collar (Includes Seal)			
15	W10521118	Seal, Drum	29	697772	Wheel, Blower			
16	W10677270	Sensor Assembly, Quad Bulkhead	30	W10211911	Housing, Blower			
			31	693995	Screw			
			32	W10693363	Fuse, Thermal (91C)			

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Door
	W10626038	Chrome
2	9742177	Screw
3	W11196020	Assembly, Outer Door
4	W11283318	Assembly, Inner Door
5	W10288126	Screw
6	W10208252	Bracket, Glass
7	W10208417	Glass, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W11183899	Seal, Glass
9	W10272388	Door, Inner
10	W11178949	Cover, Door Catch
11	W10208254	Assembly, Door Catch
12	W10208401	Assembly, Spring Catch
13	W10208414	Assembly, Door Hinge
14	W10208415	Hinge, Base

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10208398	Cap, Hinge
16	W10208419	Plate, Hinge Retainer
17	W11178950	Bumper, Door

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	W10446202	Chrome Shadow

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	80047	Kit, Dryer Repair
	346764	Kit, Hold Down
	W10315283	Kit, Door Reversing
	8522199	Kit, Dryer Vent Testing
	W10869845	Kit, Stack
	W10322470	Rack, Dryer
	W10782875	Inlet Hose, 5 ft (Cold Water)
	W10044609	Hose Kit for Steam Dryer
	W10623830	Premium Hose Kit for Steam Dryer
	W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
	W10439655	Hose, Inlet (2')
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10242307	Washer, Hose

ACCESSORY PARTS|THE FOLLOWING POWER CORD CAN BE ORDERED. IMPORTANT: CHECK LOCAL WIRING CODE REQUIREMENTS TO SEE IF ONE OF THESE MEETS YOUR NEEDS.

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	PT220L	4', 30 Amp, 3 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord