




ELECTRIC DRYER

MODELS:

WED8620HW2 (White)

WED8620HC2 (Chrome Shadow)


CONSOLE AND CABINET PARTS



CONSOLE AND CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	W11255768	Channel, Water	33	W10446781	Spring, Idler
	W11364660	Owners Manual	15	12990702	Screw	34	3387610	Belt, Drive
	W11459719	Tech Sheet	16	W10208198	Bracket, Console	35	W10121316	Clamp, Motor Mount
	W11457204	Wiring Diagram	17		Panel, Console	36	W11322192	Assembly, Motor
	W11355749	Quick Start Guide		W11314497	White	37	8066184	Pulley, Motor
	W11184895	Quick Start Guide		W11314469	Chrome Shadow	38	W11404905	Bracket, Motor Mounting
2	3390647	Screw	18	W10884773	Badge	39	W11461190	Appliance Control Unit (ACU)
3	3397659	Block, Terminal	19		Front Panel (Includes Door Hinge Bracket)	40	W10504381	Pad, Foam
4	489463	Screw		W11413344	White	41	W10653662	Pad, Foam
5	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)		W11413335	Chrome Shadow	42		Top
			20	W11084215	Bracket, Hinge		W10208383	White
6	279393	Screw Kit, Terminal Block	21	3357011	Screw		W10460919	Chrome Shadow
			22	W11126752	Strike, Door	43	343641	Screw
7	W10208382	Bracket, Rear	23	W10288126	Screw	44	W11157860	Harness, Wiring (Main)
8	W10487430	Panel, Rear	24	3387242	Seal, Front Panel	45	W11394868	Cover, Terminal Block
9	W10773242	Screw	25	W11307535	Assembly, Door Switch			
10		Panel, Side	26	W11160620	Harness, User Interface			
	W11177568	White	27	W10568405	Assembly, Speaker			
	W11177570	Chrome Shadow	28	W11231800	Seal			
11	3393008	Screw	29	3389420	Screw			
12	8565046	Base, Cabinet	30	W10547287	Assembly, Idler			
13	3392100	Foot, Dryer	31	W10468057	Assembly, Pulley			
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	32	W10121334	Washer			


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Outer Door	6	W11050690	Bracket, Door Catch	11	W11120174	Cover, Hinge
	W11114005	Chrome Shadow	7	W10208401	Assembly, Spring Catch	12	W11120683	Cover, Handle
2	W11122999	Assembly, Inner Door	8	W10288126	Screw	13	9742177	Screw
3	W11100789	Bracket, Glass	9	W11114011	Hinge Assembly			
4	W10891207	Glass, Door	10	8540479	Screw, Grounding			
5	W11183899	Seal, Glass						

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11104018	Assembly, Air Duct	17	W10521118	Seal, Drum	32	697772	Wheel, Blower
2	3390647	Screw	18	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	33	W10211911	Housing, Blower
3	W11209933	Bulkhead, Rear				34	W10693363	Fuse, Thermal (91C)
4	W11157054	Valve and Hose Assembly	19	W11344457	Element, Heater 5400W	35	8557403	Thermostat, High Limit
5	W11100488	Nozzle, Cap	20	W10672683	Assembly, Outlet Grill and Housing	36	693995	Screw
6	W10001120	Nut, Hex (Left Hand Thread)	21	3387223	Sensor, Electrode	37	W10342188	Exhaust Pipe
7	3387459	Washer	22	W10298258	Harness, Sensor	38	W10344699	Collar, Duct
8	W10512946	Washer, Tri Ring	23		Lint Screen	39	W10891205	Assembly, Weld Heater Box
9	W10359272	Shaft, Drum Roller - Left Hand Thread		W10516085	White	40	280148	Kit, Thermal Cut-Off (Includes Thermostat)
10	W10314171	Roller, Support	24	W10673491	Bulkhead, Front	41	8577274	Thermistor
11	W10359271	Shaft, Drum Roller - Right Hand Thread	25	W11203983	Assembly, Drum Light	42	8066099	Bracket, Heater Box
12	3934666	Nut, Hex	26	W11257251	Shield, Blower	43	3387230	Screw
13	W10541657	Assembly, Drum (Complete)	27	489463	Screw			
14	W10280771	Baffle, Drum	28	W10211950	Seal, Housing Outlet			
15	W10219342	Screw	29	W10211896	Assembly, Lint Duct			
16	W10521122	Seal, Drum Front	30	W10414388	Clip, Lint Duct			
			31	W11254843	Assembly, Collar (Includes Seal)			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	W10446202	Chrome Shadow
	72032	Black
	W10268217	Mercury Silver

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	80047	Kit, Dryer Repair
	346764	Kit, Hold Down
	W10315283	Kit, Door Reversing
	8522199	Kit, Dryer Vent Testing
	W10869845	Kit, Stack
	W10322470	Rack, Dryer
	W10782875	Inlet Hose, 5 ft (Cold Water)
	W10044609	Hose Kit for Steam Dryer
	W10623830	Kit, Dryer - Premium Steam Hose (Includes (1) 2' hose and (1) 5' hose, (1) Y adapter and (5) rubber washers.)
	W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
	W10439655	Hose, Inlet (2')
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10242307	Washer, Hose

CAN BE ORDERED. IMPORTANT: CHECK LOCAL WIRING CODE REQUIREMENTS TO SEE IF ONE OF THESE MEETS YOUR NEEDS.

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	PT220L	4', 30 Amp, 3 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord

ACCESSORY PARTS|THE FOLLOWING POWER CORD