




## **24" DOUBLE WALL OVEN WITH CONVECTION**

### **MODELS:**

WOD52ES4MW00 (White)  
WOD52ES4MB00 (Black)  
WOD52ES4MZ00 (Stainless)





# OVEN PARTS



# OVEN PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>        | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                  | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|---------------------------|-----------------------------|-----------------|-------------------------------------|-----------------------------|-----------------|---------------------------------|
| 1                           |                 | Literature Parts          | 9                           | W11581007       | Hinge, Running Mechanism            | 16                          | W11594209       | Bracket, Panel                  |
|                             | W11508921       | Installation Instructions | 10                          | W10518387       | Gasket, Door                        |                             |                 | FOLLOWING PARTS NOT ILLUSTRATED |
|                             | W11508845       | Use and Care Guide        | 11                          | W11348087       | Lamp, Halogen 25 Watt (with Gasket) |                             | W11594182       | Harness, Main                   |
|                             | W11568131       | Tech Sheet                | 12                          | W10517979       | Trim, Lower                         |                             | W11348047       | Kit, Power Cord (No Plug)       |
| 2                           | W11347847       | Latch, Door               | 13                          | W10545973       | Foot, Level Oven                    |                             | W11594210       | Screw Kit, Insert Panel         |
| 3                           | W11509867       | Cap                       | 14                          |                 | Liner, Oven (Not Serviceable)       |                             |                 |                                 |
| 4                           | W11594218       | Washer, Teflon            | 15                          |                 | Panel, Insert                       |                             |                 |                                 |
| 5                           | W11594207       | Probe, Oven Temperature   |                             | W11594217       | White                               |                             |                 |                                 |
| 6                           | W10549523       | Filter, Line Noise        |                             | W11594212       | Black                               |                             |                 |                                 |
| 7                           | W10578780       | Bumper                    |                             | W11594208       | Stainless                           |                             |                 |                                 |
| 8                           | W10519818       | Kit, Oven Screws          |                             |                 |                                     |                             |                 |                                 |


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                     |
|-----------------------------|-----------------|-------------------------|-----------------------------|-----------------|----------------------|-----------------------------|-----------------|----------------------------------------|
| 1                           |                 | Assembly, Control Panel | 5                           | W11594177       | PCBA, User Interface | 9                           | W10490220       | Thermostat, 165 Celcius (with Bracket) |
|                             | W11594203       | White                   | 6                           | W11348033       | Wiring, Side Control | 10                          | W10519009       | Gasket, Blower Motor                   |
|                             | W11594176       | Black                   | 7                           |                 | Trim, Vent           | 11                          | W11594206       | Board, Power                           |
| 2                           | W11348035       | Harness, Touch Display  |                             | W10914742       | White                |                             |                 |                                        |
| 3                           | W11348132       | Cover, Control          |                             | W11594195       | Black                |                             |                 |                                        |
| 4                           | W11348036       | Wiring, Right Control   | 8                           | W11347859       | Blower, Cooling Fan  |                             |                 |                                        |


# OVEN DOOR PARTS



# OVEN DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>         | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>       | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>         |
|-----------------------------|-----------------|----------------------------|-----------------------------|-----------------|--------------------------|-----------------------------|-----------------|----------------------------|
| 1                           | W10518369       | Vent, Door Trim Top        | 7                           |                 | Handle, Door             | 12                          |                 | Assembly, Lower Outer Door |
| 2                           | W10518307       | Spacer, Door Trim Top      |                             | W11594201       | White                    |                             |                 |                            |
| 3                           | 480121101609    | Glass, Door Inner Assembly |                             | W11594197       | Black                    |                             | W11594202       | White                      |
|                             |                 |                            |                             | W11594163       | Stainless                |                             | W11594198       | Black                      |
| 4                           | W10518376       | Glass, Door Inner          | 8                           | 481010387617    | Support, Oven Door Glass |                             | W11594173       | Stainless                  |
| 5                           | W10519004       | Spacer, Oven Door Glass    | 9                           | W11594161       | Hinge, Door              |                             |                 | Assembly, Upper Outer Door |
| 6                           | W10831792       | Spacer, Door Handle        | 10                          | W11509863       | Support, Oven Glass      |                             | W11594216       | White                      |
|                             |                 |                            | 11                          | W10518384       | Support, Oven Door Glass |                             | W11594211       | Black                      |
|                             |                 |                            |                             |                 |                          |                             | W11594205       | Stainless                  |

# INTERNAL OVEN PARTS





# INTERNAL OVEN PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>     | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>   |
|-----------------------------|-----------------|------------------------|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|----------------------|
| 1                           | W10762741       | Grid, Oven Rack        | 5                           | W10901439       | Nut, Fan              | 9                           | W11347861       | Element, Upper Grill |
| 2                           | W10519022       | Screw, Grid            | 6                           | W10901438       | Blade, Fan            | 10                          | W11348032       | Element, Lower       |
| 3                           | W11594175       | Baffle, Convection Fan | 7                           | W11347858       | Motor, Convection Fan |                             |                 |                      |
| 4                           | W11347860       | Element, Convection    | 8                           | W10635612       | Rack, Oven            |                             |                 |                      |