




**30" GAS FREESTANDING SELF CLEAN RANGE
Finger Print Resistant**

MODELS:

WFG550S0LZ4 (Stainless)

WFG550S0LV4 (Black Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	12	W11368533	Burner Kit
	W11404103	Installation Instructions		W11418086	Black Panel, Manifold			FOLLOWING PARTS NOT ILLUSTRATED
	W11450808	Owners Manual		W11044911	Stainless		W11457191	Harness, Main
	W11102748	Sheet, Tech (English)		W11044910	Black Stainless		W11450461	Harness, Bake/Broil
	W11524748	Quick Start Guide	6		Knob, Control		3196520	Clip, Wire
2		Burner Cap Kit		W11510456	Stainless		W10334923	Clip, Gas Wiring
	W11498499	Black (Set of 4)		W11510460	Black		313438	Clip, Harness
3	W11352018	Spreader, Flame (Left Front & Right Front)	7		Grate Kit		3196896	Clip, Wire
	W11352020	Spreader, Flame (Right Rear)	8	W11090908	Black (Set of 3)			
	W11352021	Spreader, Flame (Left Rear)	8	W11367086	Spreader, Flame			
			9	3196557	Screw			
			10	W11379945	Bracket, Anti-Tip			
			11	7101P485-60	Screw, Anti-Tip Kit			


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	7	8523412	Bracket, Rear Cooktop	16	W10475149	Module, Spark (5+0)
	W11213290	Black (Left)	8	W10198745	Cover, Upper	17	W10901802	Panel, Backer
	W11213292	Black (Right)	9	W10192841	Shield, Heat	18		Bracket, Eye Brow
2	8053505	Shield, Heat	10	W10184251	Cover, Back		W11443964	Black
3		Panel, Control	11	3196169	Screw	19	3196165	Screw
	W11448332	Stainless	12		Control, Electronic (LCX)			
	W11448333	Black Stainless		W11520700	Black			
4	W10762981	Bracket, Mounting	13	3196178	Screw			
5	W10920631	Module, Spark DSI	14	W10856361	Bracket, Control			
6	W10516123	Bracket, Console Mounting	15	W10797001	Bracket, Ignitor			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11577792	Screw, Valve	9	W10224921	Bracket, Aegis	25	W10673618	Screw
2	W10949105	Bracket, Saddle Valve	10	3196385	Screw			FOLLOWING PARTS NOT ILLUSTRATED
3	W11459257	Orifice Holder Assembly (15K) (Left Front)	11	3400016	Screw		W11489399	LP 5 Orifice Conversion Kit
	W11459258	Orifice Holder Assembly (9.5K) (Left Rear)	12	8054078	Burner, Broiler		W10566537	LP Bake and Broil Kit
	W11459260	Orifice Holder Assembly (15K) (Right Front)	13	W10184491	Spreader, Flame (Oven)		W10400495	Orifice, LP Bake
	W11459259	Orifice Holder Assembly (5K) (Right Rear)	14	9758078	Burner, Bake		W10465080	Orifice, LP Broil
	W11459261	Orifice Holder Assembly (8K) (Center)	15	W11370883	Regulator		W10182767	Tie, Manifold Wire
4	W10215439	Tubing (Manifold to Regulator)	16	W10333842	Electrode, Broil			
5	W11537754	Harness, Igniter (Includes Switches)	17	W10420040	Tube, Broiler Supply			
6	W11450459	Electrode, Bake	18	W11435700	Fitting, Broiler			
7	W11510000	Manifold Assembly	19	W11485872	Orifice (15K) (Left Front & Right Front)			
8	W11509685	Valve, Gas (Left Front & Right Front)		W11485873	Orifice (9.5K) (Left Rear)			
	W11509686	Valve, Gas (Left Rear, Center)		W11485871	Orifice (5K) (Right Rear)			
	W11509687	Valve, Gas (Right Rear) (Center)		W11485874	Orifice (8K) (Center)			
			20	W10137062	Spreader, Flame (Broiler)			
			21	3196265	Screw			
			22	W10362924	Screw			
			23	W10827923	Electrode, Spring			
			24	W11428831	Electrode (Left Front, Left Rear)			
				W11428858	Electrode (Right Front, Right Rear, Center)			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	17	9757239	Rod, Door Switch	33	W10674705	Glide, Drawer Front
2	8272747	Shield, Flue	18	W10031780	Screw	34	3196178	Screw
3	W11379351	Box-Burner, Gas Sealed	19	3400080	Screw	35	W11173792	Rack, Oven
4		Panel, Side	20	W10919715	Gasket	36	W11403615	Fan Motor, Convection
	W10162245	Black	21	W11491751	Seal, Door	37	W11425715	Blade, Fan
5	W10137382	Clip, Panel	22	W10435470	Brace, Main Back	38	W11433702	Nut, Acorn (LH)
6	8523249	Bracket, Manifold	23	W11379353	Retainer, Insulation (Left)	39	4449809	Screw
7	W10362924	Screw		W11379943	Retainer, Insulation (Right)	40	W10134126	Bracket, Fan
8	3196560	Screw	24	3196560	Screw	41	W10134124	Cover, Conv Fan
9	W10341186	Front Foot Assembly	25	W10910642	Cord, Power	42	W10158780	Cover, Rear Fan
10	W10058460	Foot, Leveling	26	W10289077	Receiver, Hinge	43	W11526015	Basket, Air Fry
11	3195097	Bottom, Oven	27	W11511828	Switch, Door			FOLLOWING PARTS NOT ILLUSTRATED
12	W10586204	Sensor	28	W11544377	Light Assembly		8524099	Insulation, Wrap
13	8053967	Baffle, Burner Oven	29	W10571723	Bulb, Halogen 40 Watts		W10180437	Insulation, Back
14	8053969	Shield, Heat	30	9761013	Front Door Latch Assembly			
15	8053968	Shield, Lower	31	W10078370	Rod, Push Latch			
16	W10390008	Base Rail Assembly (Left)	32	W10107820	Rear Door Latch Assembly			
	W10390007	Base Rail Assembly (Right)						


DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly	9	9761357	Retainer, Insulation	14	W11379944	Strap, Door
	W11242950	Stainless	10	W10299224	Hinge, Active (With Spring)	15	W10299227	Hinge, Door (Passive)
	W11242951	Black Stainless	11		Glass, Outer Door (Includes Nameplate)	16	W10884775	Badge
2	W10480830	Screw		W10884159	Black	17		Trim, Lower
3	W10200660	Screw	12		Trim, Door		W11444043	Black
4	9761344	Liner, Door		W10746436	Black (Left)			
5	W10031790	Screw		W10746435	Black (Right)			
6	W11044424	Glass, Inner	13	W10327235	Screw			
7	W10316950	Frame, Glass						
8	W10278991	Insulation, Door Strip						

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10674708	Glide, Drawer Rear	4		Panel, Drawer Front
2	W10688022	Drawer, Storage		W11190210	Stainless
3	W10462909	Bracket, Mounting		W11450003	Black Stainless
			5	3196169	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting