




ELECTRIC DRYER

MODELS:

WED500CMW0 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	3390663	Screw	14		Assembly, Control Knob
	W11555817	Owners Manual	8		Lint Screen		W11406489	Chrome
	W11565129	Tech Sheet		W11538108	White	15		Assembly, Console
	W11423864	Quick Start Guide	9	W11374901	Encoder, Mega Assembly		W11406485	White
2	W11551859	HMI Harness	10	688983	Screw	16	8536939	Clip, Spring
3	W11606406	Appliance Control Unit (ACU)	11	3348629	Screw	17	343641	Screw
4	W10775189	Panel, Rear	12		Top	18	W10662472	Collar, Lint Chute
5	W11568017	Harness, Main		W10613389	White	19	W11445460	Assembly, Fascia
6	8312709	Clip, Console	13	W10298336	Nut, "U"	20	9740848	Screw


CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10529198	Cover, Door Catch	18		Cabinet	31	3397659	Block, Terminal
2	3390631	Screw		8530603	White	32	3401800	Shield, Belt Assembly
3	693995	Screw	19		Panel, Front	33	W10121316	Clamp, Motor Mount
4	W10841728	Seal, Spill Guard		W10664697	White	34	W10396039	Motor Assembly 60 Hz.
5	W11219688	Cover, Terminal Block	20	W11224633	Strike, Door			
6	W10567345	Plug, Strike	21	W10803476	Assembly, Seal and Bearing	35	8066184	Pulley, Motor
7	W11598681	Panel, Rear	22	W11224630	Assembly, Door Catch	36	691366	Idler Assembly
8	8066092	Lock, Front Top	23	342055	Screw	37	3387610	Belt, Drive
9	98234	Clip, Ground	24		Assembly, Hinge and Pin	38	3401801	Base, Motor
10	W11590193	Switch, Door				39	3400500	Bolt
11	697773	Screw		W10362431	White	40	W10641296	Hinge, Top
12		Hinge Hole Cover	25	W10730752	Seal, Door	41	W10316529	Seal, Foam
	W11308618	White	26	W10463967	Door, Inner	42	W10641295	Bracket, Rear
13	685203	Clip, Felt Pad	27		Door, Front	43	W10316619	Seal, Spill Guard
14	3393008	Screw		W10714510	White	44	9740848	Screw
15	W10775448	Clip, Front Panel	28		Handle, Door	45	W11532648	Pad, Power Cord
16	W10779369	Foot, Dryer		W10714516	White	46	W10529197	Bezel, Door Catch
17	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)	29	279393	Screw Kit, Terminal Block	47	343641	Screw
			30	W10773242	Screw	48	W10653662	Pad, Foam
						49	3401805	Bracket, Idler

BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798024	Assembly, Lint Chute	17	W10724237	Element, Heater	32	692526	Bearing, Ring
2	W11424720	Pad, Sensor	18	W10836094	Pad, Sound	33	W10219342	Screw
3	3388703	Washer	19	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	34	W10856781	Seal, Rear Drum
4	347139	Seal, Lint Chute				35	W10757750	Assembly, Drum (Complete)
5	90767	Screw	20	489463	Screw	36	692490	Baffle, Drum (Long)
6	W10389567	Shield, Exhaust	21	3390647	Screw	37	W11032820	Bracket, Support
7	3392519	Fuse, Thermal (91C)	22	3406124	Bulb, Light	38	90296	Nut, Push On
8	8577274	Thermistor	23	3402841	Lens, Drum Light	39	3403636	Baffle, Drum (Short)
9	W10900067	Kit, Thermal Cut-Off (Includes Thermostat)	24	W10512946	Washer, Tri Ring	40	339956	Seal
10	W10709771	Wheel, Blower	25	W10359270	Shaft, Drum Roller - Left Hand Thread			
11	8577230	Housing, Blower	26	W10359269	Shaft, Drum Roller - Right Hand Thread			
12	3398161	Clip, Heater Box						
13	3390631	Screw	27	3397590	Roller, Support			
14	W11338355	Box, Heater	28	348197	Washer			
15	3977767	Thermostat, 221 F (105 C)	29	W10298789	Nut, Hex			
			30	W10714469	Bulkhead			
16	3977373	Bracket, Drum Light	31	W10214261	Socket, Light			

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

	72017	White
--	-------	-------

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

	799344	White (Uncut)
--	--------	---------------

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

	279948	Kit, Dryer Repair
	346764	Kit, Hold Down
	8522199	Kit, Dryer Vent Testing
	W10322470A	Dry Rack
	W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
	W10439655	Hose, Inlet (2')
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10242307	Washer, Hose

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
-------------------	-----------------	--------------------

	80047	Kit, Dryer Repair
	3406839	Dry Rack
		Power Cords
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT220L	4', 30 Amp, 3 Wire, Dryer Cord
	W10242307	Washer, Hose
	W10336486	Connector, Hose -"Y"
	3976300	Washer, Inlet Hose