




## REFRIGERATOR

### MODELS:

WUB35X24HZ02 (Stainless)


# CABINET PARTS



# CABINET PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                                   | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|------------------------------------------------------|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|--------------------|
| 1                           |                 | Cabinet (Not A Service Part)                         | 10                          | W11311389       | Support            | 22                          | 4344763         | Leg, Leveling      |
| 2                           | W11312450       | Cover, LED                                           | 11                          | W11311645       | Control Assembly   | 23                          | W11492236       | Box, Switch        |
| 3                           | W11312453       | LED Assembly                                         | 12                          | W11263886       | Glass Shelf        | 24                          | W11371100       | Screw              |
| 4                           | W11311383       | Shelf, Glass                                         | 13                          | W11312493       | Wine Rack          | 25                          | W11265575       | Brace              |
| 5                           | W11312455       | Assembly, Fan Cover (Includes Fan Motor, and Sensor) | 14                          | W11312494       | Wine Rack, Lower   | 26                          | W11265587       | Switch, Door       |
| 6                           | W11263845       | Defrost Heater and Holder                            | 15                          | W11312540       | Box, Control       | 27                          | W11313093       | Support, Side      |
| 7                           | W11371095       | Screw                                                | 16                          | W11359415       | Fuse, Temperature  | 28                          | W11371097       | Screw              |
| 8                           | 4344796         | Screw                                                | 17                          | W11312550       | Trim, Sash         | 29                          | W11265577       | Seal, Condenser    |
| 9                           | W11311388       | Shelf, Support                                       | 18                          | 4344829         | Tie, Cable         | 30                          | W11371103       | Screw              |
|                             |                 |                                                      | 19                          | W11263884       | Sensor, Defrost    |                             |                 |                    |
|                             |                 |                                                      | 20                          | W11239541       | Grille             |                             |                 |                    |
|                             |                 |                                                      | 21                          | W11371101       | Screw              |                             |                 |                    |

# DOOR PARTS




# DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 1                           | W11310653       | Handle, Towel Bar  |
| 2                           | 4344796         | Screw              |
| 3                           | W11264668       | Hinge, Top         |
| 4                           | W10319186       | Screw              |
| 5                           | W11264645       | Hinge Mount        |
| 6                           | W11265573       | Closer             |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 7                           | W11371097       | Screw              |
| 8                           | W11371100       | Screw              |
| 9                           |                 | Wrap, Door         |
|                             | W11624960       | Stainless          |
| 10                          | W11624965       | Foam, Door         |
| 11                          | W11312621       | Gasket, Door       |
| 12                          | W11264669       | Actuator, Switch   |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 13                          | W11371345       | Screw              |
| 14                          | W11264678       | Door Stop          |
| 15                          | W10772902       | Stud, Mounting     |
| 16                          | W11476742       | Assembly, Door     |
| 17                          | W10797377       | Screw              |
| 18                          | W11264644       | Washer             |
| 19                          | W10622815       | Plate, Door Handle |

# UNIT PARTS



# UNIT PARTS

Illus.  
No.   Part No.   Description

|    |           |                     |
|----|-----------|---------------------|
| 1  | W11375763 | Screw               |
| 2  | W11538057 | Pan, Water          |
| 3  | W11313136 | Fan Motor           |
| 4  | W11265584 | Assembly, Fan Motor |
| 5  | W11265569 | Clamp               |
| 6  | W11264703 | Cover, Rear         |
| 7  | W11371097 | Screw               |
| 8  | W11633778 | Brace               |
| 9  | W11371100 | Screw               |
| 10 | W11313206 | Cover, PCB          |
| 11 | W11614616 | Control, Electronic |
| 12 | W11313209 | PCB Box             |

Illus.  
No.   Part No.   Description

|    |           |                                      |
|----|-----------|--------------------------------------|
| 13 | W11568820 | Cover                                |
| 14 | W11614619 | PTC Relay                            |
| 15 | W11538055 | Compressor                           |
| 16 | 4344779   | Grommet,<br>Compressor               |
| 17 | 4344780   | Bolt, Compressor                     |
| 18 | W11498145 | Cord, Power                          |
| 19 | W11576947 | Clamp, Cord                          |
| 20 | W11614621 | Wire                                 |
| 21 | W11538053 | Capacitor                            |
| 22 | W10805035 | Drier (Service Drier<br>Without Dye) |
| 23 | W11263876 | Harness, Wire                        |

Illus.  
No.   Part No.   Description

|    |           |                       |
|----|-----------|-----------------------|
| 24 | 4344797   | Screw                 |
| 25 | W10322070 | Washer                |
| 26 | W11360595 | Compressor, Rubber    |
| 27 | W11614617 | Protector, Motor      |
|    |           | REFRIGERANT<br>CHARGE |
|    |           | 52 grams (R600a)      |