




Dishwasher

MODELS:

WDF341PAPB2 (Black)
WDF341PAPW2 (White)
WDF341PAPT2 (Biscuit)
WDF341PAPM2 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Panel Front	6	W10315897	Insulation, Front Panel
	W11655293	Energy Guide		W11546165	Black	7	8268961	Sleeve, Friction
	W11532445	Owners Manual		W11546166	White	8		Fastener
	W11532444	Tech Sheet		W11546172	Biscuit		W10503548	Black
2		Arm, Hinge		W11546173	Stainless		W10503549	White
	W11546151	Left Hand	5		Access Panel		W10503550	Biscuit
	W11546150	Right Hand		W10799402	Black	9	W10519755	Insulation, Toe Panel
3	W10803537	Stiffener, Door		W10799403	White	10	489470	Screw
				W10799404	Biscuit			


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)	2	W10825638	Box, Connector	7	W11665215	Control, Electronic
	W11546167	Black	3	W11549367	Handle, Upper	8	W10825369	Brace, Connector
	W11546168	White	4	W10574864	Latch Assembly (Includes Switch)	9	W11549368	Light Pipe w/ integrated button tree
	W11546169	Biscuit	5	W10711884	Screw			
	W11546171	Stainless	6	W10348408	Screw			


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	5	W10329609	Vent Assembly (Also Order Item 4)	9	W10274923	Seal, Console/Door
2	W11467680	Inner Door (Also Order Item 4)	6	W10428217	Dispenser, Assembly	10	W10462232	Bracket, Dispenser
3	W10482094	Cover, Dispenser	7	W11595228	Wiring Harness	11	W10524922	Cap, Rinse Aid
4	8269259	Gasket, Vent	8	W10177098	Screw	12	W10334900	Bezel, Vent


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11669944	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11467711	Tub Assembly (Includes Heater Assembly)	11	W10277003	Screw	21	W10732961	Bracket, Heater Support
2	W11656602	Shield, Thermostat	12	8268991	Cover, Terminal Box	22	W10441445	Heater Element Assembly
3	W11425053	Seal, Tub	13	W10866979	Shield, Tub Sound			(Includes Heater Washer & Nut)
4	W10341745	Screw	14	W11525335	Clip, Thermostat			
5	3367670	Screw	15	3371618	Thermostat			
6	8269145	Bracket, Undercounter	16	W10544004	Strike, Latch			NOTE: If heater element is removed, it must be replaced.
7	W11623675	Support, Bottom	17	3378128	Washer, Pronged Cup			
8	W10619352	Leveler, Leg	18	3400014	Screw, Grounding	23	8270018	Wheel
9	W10337934	Spring, Door Balance	19	8268990	Bushing, Door Spring	24	3400892	Screw
10	8575897	Wheel Assembly	20	W10819539	Sound Insulation, Bottom			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	6	W10372113	Tab, Sump	15	W10195086	Motor, Isolator
2	W10482462	Sump With Seal (Also Order Items 13 & 16)	7	W10789806	Filter Cup Assembly	16	W10445975	Hose Assembly (Includes 2 Clamps)
3	W10463906	Screen	8	W10724439	Pump, Drain	17	W10491331	Sprayarm
4	W11521435	Motor (Also Order Items 13 & 16)	9	8269144	Hose, Drain			
5	W11525546	Sump & Motor Assembly	10	W10348407	Screw			
			11	370445	Clamp, Hose			
			12	W11525024	Sensor, Temperature			
			13	W11182008	Grommet			
			14	W10169167	Clamp, Hose			


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11462355	Feed Tube Assembly	3	W10498900	Sprayarm
2	W10165274	Screw	4	W10340681	Manifold


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10826745	Dishrack, Upper	3	3385089	Track, Dishrack	5	W10306228	Track, Spacer
2	W10845760	Mount, Wheel Assembly	4	8565925	Stop, Track (Non-Removable)	6	3379676	Wheel

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8561705	Dishrack, Lower
2	8268645	Wheel & Transport Assembly
3	8562045	Basket, Silverware (Assembly)

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
8171656		White
8171657		Black
8171658		Biscuit/Bisque
8171659		Stainless Steel
		MOISTURE BARRIER KIT
4396277		Barrier Kit
		DRAIN HOSE
3385556		12 Ft. Touch Up Paint
72017		White
72032		Black
4392899		Biscuit and Bisque
4317824		Power Cord Kit (Included Cord & Misc. Hardware)
8171477		Floor Mount Kit
8212560		Side Mount Kit
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
4396854		Silver Atlantis