




ELECTRIC DRYER

MODELS:

WHD560CHW2 (White)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	343641	Screw	11		Panel, Console
	W11184587	Use and Care Guide	4	W11255768	Channel, Water		W11296380	White
	W11184511	Installation Instructions	5	12990702	Screw	12	W10219342	Screw
	W11184896	Quick Start Guide	6	W10208198	Bracket, Console	13	W10884773	Badge
	W11457205	Wiring Diagram	7	3390647	Screw	14	W11157870	Wiring Harness (Upper)
2		Top	8	W11160620	Harness, User Interface	15	693995	Screw
	W10208383	White	9	W11231800	Seal			
			10	W10568405	Assembly, Speaker			


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11394868	Cover, Terminal Block	14	W10608849	Seal - Strip	26	W10802056	Box Assembly, Secondary Lint
2	3390647	Screw	15	3392100	Foot, Dryer			
3	3397659	Block, Terminal	16	W11307535	Assembly, Door Switch	27		Bezel, Secondary Lint Assembly
4	3390631	Screw	17		Front Panel		W11194428	White
5	W10668463	Bracket, Terminal Cross Bar		W11421256	White	28	W10810480	Guard, Fan
6	W10773242	Screw	18	W11084215	Bracket, Hinge	29	W10705660	Hose, Outlet
7	W10208382	Bracket, Rear	19	W11126752	Strike, Door	30	3391018	Tie, Cable
8	W10524494	Panel, Rear	20	W10288126	Screw	31	279393	Screw Kit, Terminal Block
9	3393008	Screw	21	3387242	Seal, Front Panel	32	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
10		Panel, Side	22	3357011	Screw			
	W11177568	White	23		Door, Secondary Lint			
11	W11461222	Appliance Control Unit (ACU)		W11108733	White			
12	W10504381	Pad, Foam	24	W10739609	Assembly, Handle - Secondary Lint			
13	W10686117	Seal - Strip	25	W10739605	Filter, Secondary Lint			


BASE PARTS



BASE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10608831	Cover, Heat Exchange	11	W10754439	Filter, Service	23	W10468057	Assembly, Pulley
2	W10651558	Switch, Lint Screen	12	W10647273	Lint Housing Extension	24	W10651995	Assembly, Motor Capacitor
3	W10219342	Screw	13	693995	Screw	25	W10121316	Clamp, Motor Mount
4	W10837311	Housing, Auxillary Fan	14	W10364994	Blower Wheel	26	W10604214	Nut
5	W10724418	Capacitor, Compressor	15	90767	Screw	27	W10724414	Capacitor, Motor Run
6	W11175941	Fan, Compressor	16	8577274	Thermistor	28	W10442513	Capacitor, Motor Start
7	12990515	Screw	17	W10574749	Bracket, Thermister	29	W11109746	Wiring Harness (Lower)
8	W11177749	Drain Pump	18	W10467289	Sensor, Temperature	30	W10645092	Bracket, Valve
9	W10459416	Seal Strip	19	W10578065	Bracket, Motor			
10		Not Serviced	20	W10446781	Spring, Idler			
	W11368564	Base Assembly (Not Serviced)	21	3389420	Screw			
			22	W10547287	Assembly, Idler			


BULKHEAD PARTS



BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10660495	Assembly, Inlet Duct	13	W10359272	Shaft, Drum Roller - Left Hand Thread	25	W10521122	Seal, Drum Front
2	3390647	Screw	14	3387610	Belt, Drive	26	W11203353	Assembly, Filter - Primary Lint
3	W10732729	Thermostat	15	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)	27	W10539315	Assembly, Outlet Grill & Housing
4	W10643339	Assembly, Inlet-Heater Duct	16	W10642437	Lint Duct	28	W10670373	Assembly, Door Housing Outlet
5	W10709255	Edge Cover, Inlet Duct	17	W10211950	Seal, Housing Outlet	29	W10219016	Door, Lint Screen
6	W10653662	Pad, Foam	18	3390631	Screw	30	W10834437	Spring, Lint Screen Door
7	W11162462	Bulkhead, Rear	19	3934666	Nut, Hex	31	W10684400	Outlet Grill
8	W10001120	Nut, Hex (Left Hand Thread)	20	W10673493	Bulkhead, Front	32	W10298258	Harness, Sensor
9	3387459	Washer	21	W10508188	Assembly, Drum (Complete)	33	3387223	Sensor, Electrode
10	W10512946	Washer, Tri Ring	22	W10521118	Seal, Drum			
11	W10359271	Shaft, Drum Roller - Right Hand Thread	23	W10219342	Screw			
12	W10314171	Roller, Support	24	W10416098	Baffle, Drum			

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Outer Door	6	W11050690	Bracket, Door Catch	11	W11120174	Cover, Hinge
	W11114013	White	7	W10208401	Assembly, Spring Catch	12	W11120683	Cover, Handle
2	W11122999	Assembly, Inner Door	8	W10288126	Screw	13	9742177	Screw
3	W11100789	Bracket, Glass	9	W11114011	Hinge Assembly			
4	W10891207	Glass, Door	10	8540479	Screw, Grounding			
5	W11183899	Seal, Glass						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	W10446202	Chrome Shadow

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	80047	Kit, Dryer Repair
	346764	Kit, Hold Down
	W10315283	Kit, Door Reversing
	8522199	Kit, Dryer Vent Testing
	W10869845	Kit, Stack
	W10886894	Dry Rack
	W10782875	Inlet Hose, 5 ft (Cold Water)
	W10044609	Hose Kit for Steam Dryer
	W10623830	Kit, Dryer - Premium Steam Hose (Includes (1) 2' hose and (1) 5' hose, (1) Y adapter and (5) rubber washers.)
	W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
	W10439655	Hose, Inlet (2')
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10242307	Washer, Hose