




GAS COOKTOP

MODELS:

WCGK5036PS00 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W11352193	Flame Spreader (Left Front and Center)	12	W11640975	Wiring, Electrode (440MM)
	W11613935	Owner's Manual		W11352197	Flame Spreader (Left Rear)		W11642338	Wiring, Electrode (636MM)
	W11635589	Quick Start Guide		W11352195	Flame Spreader (Right Front and Right Rear)	13	W10826075	Rear, Hinge-Grate (Stainless Model Only)
2		Cooktop				14	W10598131	Foot Pad, Grate (Outer)
	W11585231	Stainless	9		Grommet			FOLLOWING PARTS NOT ILLUSTRATED
3		Burner Cap Kit		W10625915	Black		W11632719	Harness (Switch), Main
	W11596821	Black (Set of 5)	10	W10758282	Screw		W10878749	Harness, Spark Module
4		Grate Kit		W11364991	Orifice (Left Front)		3400015	Screw, Grounding
	W11591618	Black (Set of 3)	11	W10723360	Orifice (Left Rear)		W10392003	Cord, Power
5	W10827923	Electrode, Spring		W11610057	Orifice (Center)		W10132200	Relief, Strain
6		Knobs, Cooktop		W11631338	Orifice (Right Front and Right Rear)		313438	Clip, Harness
	W11576416	Stainless					W11573776	LP Conversion Kit
7	W11567145	Holder, Orifice (12K) (Left Front)					3801F935-51	Bracket, Tie Down
	W11567151	Holder, Orifice (5K) (Left Rear)					7101P062-60	Screw (For Tie Down Bracket)
	W11567144	Holder, Orifice (18K) (Center)						
	W11567146	Holder, Orifice (9.1K) (Right Front and Right Rear)						

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	7	W10449143	Regulator, Pressure	15	7101P426-60	Screw
2	W11576641	Manifold Assembly	8	W11566469	Bracket, Orifice Holder	16	W10443110	Screw
3	W11629615	Valve, Single (Left Front and Center)	9	W11350452	Spark Module	17	3196537	Screw
	W11629616	Valve, Single (Left Rear)	10		Box, Burner (Not Serviced)	18	8286921	Screw, Burner Rail (M4)
	W11629617	Valve, Single (Right Front and Right Rear)	11	W11573975	Tube, Gas (Left Front)	19	W11573983	Tube, Gas (Center)
4	8287055	Bracket, Single Valve	12	W11573977	Tube, Gas (Left Rear)	20	W11704153	Bracket, Orifice Holder Center Burner
5	W11507167	Seal, Switch Shaft	13	W11573979	Tube, Gas (Right Front)			OPTIONAL ACCESSORY PART (NOT INCLUDED)
6	W11620861	Panel, Front	14	W11573978	Tube, Gas (Right Rear)		W10685483	Griddle