




GAS DRYER

MODELS:

MGD5630MBK1 (Volcano Black)


TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	2		Top	6	W11480682	Bracket, Console
	W11361424	Owners Manual		W11200177	Black	7	W10146359	Screw
	W11459720	Tech Sheet	3	693995	Screw	8		Assembly, Console
	W11460669	Wiring Diagram	4	W11255768	Channel, Water		W11580417	Black
	W11550671	Quick Start Guide	5	12990702	Screw	9	W11157863	Harness, Main Wiring


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8317339	Cover, Terminal Block	14	W11307535	Assembly, Door Switch	27	3389420	Screw
2	3390647	Screw	15	W10612925	Badge	28	W11322192	Assembly, Motor
3	W10773242	Screw	16	3387242	Seal, Front Panel	29	8066184	Pulley, Motor
4	W10208382	Bracket, Rear	17	3357011	Screw	30	W10121316	Clamp, Motor Mount
5	W10487431	Panel, Rear	18		Plug, Front Panel	31	W11404905	Bracket, Motor Mounting
6		Panel, Side (Left)		W11564884	Black	32	W10774832	Switch, Broken Belt
	W11194423	Black	19	W10288126	Screw	33	343641	Screw
7		Panel, Side (Right)	20	W10208250	Strike, Door	34	W11575710	Belt, Drive
	W11194424	Black	21		Panel, Front	35	W11308561	Cord, Power
8	W11529152	Appliance Control Unit (ACU)		W11590899	Black	36	489463	Screw
9	693995	Screw	22	3978776	Bracket, Gas Pipe			DRYER EXHAUST KIT NOT INCLUDED
10	W10504381	Pad, Foam	23	W10547287	Assembly, Idler	W10323246		Kit, 4-Way Vent
11	8529757	Bracket, Burner	24	W10468057	Assembly, Pulley			
12	8565046	Base, Cabinet	25	W10512946	Washer, Tri Ring			
13	3392100	Foot, Dryer	26	W10446781	Spring, Idler			

BULKHEAD PARTS




BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10293765	Assembly, Air Duct	14	W10414388	Clip, Lint Duct	27	8573713	Cut-Off, Thermal
2	3390647	Screw	15	W11655534	Assembly, Collar (Includes Seal)	28	338906	Sensor, Radiant
3	W10001120	Nut, Hex (Left Hand Thread)	16	697772	Wheel, Blower	29	W10508188	Assembly, Drum (Complete)
4	3387459	Washer	17	W10211911	Housing, Blower	30	W10521122	Seal, Drum Front
5	W10359271	Shaft, Drum Roller - Right Hand Thread	18	693995	Screw	31	W10416098	Baffle, Drum
6	W10512946	Washer, Tri Ring	19	W10693363	Fuse, Thermal (91C)	32	W10219342	Screw
7	W10314171	Roller, Support	20	8577274	Thermistor	33	W10521118	Seal, Drum
8	W10359272	Shaft, Drum Roller - Left Hand Thread	21	W10342188	Exhaust Pipe	34	3387230	Screw
9	W10673493	Bulkhead, Front	22	W10344699	Collar, Duct	35	W10672683	Assembly, Outlet Grill and Housing
10	3934666	Nut, Hex	23	W10623852	Thermistor, Gas Inlet	36	3387223	Sensor, Electrode
11	W11162462	Bulkhead, Rear	24	W10920818	Jumper, Harness HMI (Board to Board)	37	W10298258	Harness, Sensor
12	W10211950	Seal, Housing Outlet	25	3391912	Thermostat, Hi Limit	38		Lint Screen
13	W10211896	Assembly, Lint Duct	26	8573824	Funnel, Burner		W10516085	Gray

BURNER ASSEMBLY PARTS


USE WITH TYPE 1 - NATURAL,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11564941	Burner Assembly 60 Hz.	8	3387057	Screw	15	3387561	Clamp, Pipe
2	688617	Tube, Burner	9	3389871	Base, Burner	16	3389889	Bracket, Support
3	694298	Bracket, Ignitor	10		Orifice, Burner			Following Parts Not Illustrated
4	686590	Ignitor		15418	Type 1 (Natural)			
5	W10366705	Screw	11	326049536	Screw	W11581317		Kit, LP Gas Dryer Conversion
6	343641	Screw	12	W10328463	Coil (60 Hz)			
7	W11564944	Valve, Gas 60 Hz. (Complete)	13	W10295523	Pipe Plug			
			14	3390647	Screw			

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Door	8	W10891207	Glass, Door	15	W10208419	Plate, Hinge Retainer
	W10626039	Black	9	W11178949	Cover, Door Catch	16	W11178950	Bumper, Door
2	9742177	Screw	10	W10208254	Assembly, Door Catch			
3	W11196020	Assembly, Outer Door	11	W10208401	Assembly, Spring Catch			
4	W11218177	Assembly, Inner Door	12	W10208414	Assembly, Door Hinge			
5	W10288126	Screw	13	W10208415	Hinge, Base			
6	W11096008	Bracket, Glass	14	W10208398	Cap, Hinge			
7	W11183899	Seal, Glass						

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	W10446202	Chrome Shadow

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	80047	Kit, Dryer Repair
	346764	Kit, Hold Down
	W10315283	Kit, Door Reversing
	8522199	Kit, Dryer Vent Testing
	W10869845	Kit, Stack
	W10886894	Dry Rack
	W10782875	Inlet Hose, 5 ft (Cold Water)
	W10044609	Hose Kit for Steam Dryer
	W10623830	Kit, Dryer - Premium Steam Hose (Includes (1) 2' hose and (1) 5' hose, (1) Y adapter and (5) rubber washers.)
	W10676169	BAG ASSEMBLY, INCLUDES THE FOLLOWING:
	W10439655	Hose, Inlet (2')
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10242307	Washer, Hose