


AMANA®

ELECTRIC RANGE (Radiant Elements)

MODELS:

AER6303MMS1 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5	8273993	Element (1800W)	8	W11379945	Bracket, Anti-Tip
	W11469631	Quick Start Guide			(Left Front and Right Rear)	9	7101P485-60	Screw, Anti-Tip Kit
	W11509598	User Instructions		W10248261	Element (1200W)			FOLLOWING PARTS NOT ILLUSTRATED
	W11326823	Tech Sheet			(Right Front and Left Rear)		W11452627	Harness, Wire (Main)
2	W11600012	Spring, Element	6	3196169	Screw		W11171894	Harness, Cooktop (Left)
3	W10691223	Pan, Radiant Element	7	W10607641	Bracket, Cooktop (Left)		W11134551	Harness, Cooktop (Right)
4		Cooktop		W10607642	Bracket, Cooktop (Right)			
	W10853124	Black						


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	4	3148952	Switch, Infinite (Yellow)	7		Knobs
	W11130372	Black (Left)					W10844801	Black
	W11130379	Black (Right)			(Right Front and Left Rear)	8	W10134247	Shield, Heat
2	W10525121	Bracket, Console Mounting		3148953	Switch, Infinite (Green)	9	3400882	Screw
3		Panel, Console			(Left Front and Right Rear)	10	8272473	Cover, Upper Rear
	W11157018	Stainless				11		Control, Electronic (LCX)
			5	W10695491	Bracket, Control		W11511568	Black
			6	3196178	Screw			


CHASSIS PARTS



CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge	14	W10137382	Clip, Panel	25	W10571723	Bulb, Halogen 40 Watts
2	W10134285	Tube, Vent	15	W10390007	Base Rail Assembly (Right)	26	W10281322	Kit, Bare Wire Adapter Block
3		Panel, Side				27	3196154	Screw
	W10162245	Black		W10390008	Base Rail Assembly (Left)	28	W10910404	Counterweight
4	3400029	Nut	16	W10058460	Foot, Leveling	29	W11464547	Bracket, Front Frame
5	W10129032	Seal, Door	17	3196548	Fuse, Thermal	30	W11510560	Barrier Rail, Rubber (Left and Right)
6	9757340	Element, Broil	18	3196172	Screw			FOLLOWING PARTS NOT ILLUSTRATED
7	W11111743	Element, Bake	19	W10404688	Clip, Oven Support			
8	W10326122	Cover, Terminal Block	20	3186034	Bracket, Service			
9	3196169	Screw	21	W10245259	Block, Terminal			
10	W11173792	Rack, Oven	22	W11034869	Screw	W10333344		Insulation, Flue
11	W10341186	Front Foot Assembly	23	W10181986	Sensor, Oven	8273263		Insulation, Wrap
12	W10067840	Screw	24	W11634772	Light Assembly	8272611		Insulation, Back
13	8054068	Retainer, Insulation						

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Top
	W10310922	Black
2	W10168559	Screw
3		Handle, Door
	W10323589	Black
4	9761344	Liner, Door
5	W10031790	Screw
6	W11367326	Glass, Inner

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W11380221	Retainer, Insulation
8	W10299225	Hinge, Active
9		Badge
	W10846752	Stainless
10		Trim, Side
	W10746436	Black (Left)
	W10746435	Black (Right)
11	W10327235	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12		Glass Assembly, Outer Door
	W11602914	Stainless
13	W11379944	Strap, Door
14	W10200660	Screw
15	W10299227	Hinge, Door (Passive)
16	W11440159	Trim, Bottom Door

DRAWER AND BROILER PARTS



DRAWER AND BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10462910	Bracket, Mounting Drawer	4	W10674708	Glide, Drawer Rear
	W10330070	Stainless					W10674705	Glide, Drawer Front
2	W10688022	Drawer, Storage				5	3196165	Screw

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	8212473	Universal Silver
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	3191048	Glass Cleaner
	4396923	Broiler Pan and Grid