



## Dishwasher


### MODELS:

WDT550SAPB0 (Black)

WDT550SAPW0 (White)

WDT550SAPZ0 (Stainless)


# DOOR AND PANEL PARTS



# DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W11545693	Support, Door (Left)	20	W11625156	Panel, 4" Adjustable (Black)
	W11589935	Owners Manual		W11545696	Support, Door (Right)	21	W10942053	Screw
	W11615385	Energy Guide	9	W11564603	Insulation, Inner Door	22	W11381263	Screw
	W11589945	Tech Sheet	10	W11641124	Insulation, Front Panel			
2		Arm, Hinge	11	W11634283	Nut, Barrel			
	W11507818	Left Hand	12	302868	Screw (Black)			
	W11507890	Right Hand	13	W11625159	Panel, 2" Adjustable (Black)			
3	W11126789	Cross Brace, Door	14	W10942031	Screw			
4	W11102920	Light Pipe	15	W10941985	Screw			
5	W11625157	Panel, Main Access (Black)	16	W11049903	Stud, Mounting			
6		Front Panel (Includes 4,7,8,10,11,16,17 & 22)	17	W10316572	Screw			
	W11545707	Black	18		Handle Assembly			
	W11545699	White		W11439701	Black			
	W11545706	Stainless		W11439697	White			
7	W10884775	Badge		W11439703	Stainless			
			19	W10693137	Screw, Set			


# CONTROL PANEL AND INNER DOOR PARTS



# CONTROL PANEL AND INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)	2	W11545948	Wiring Harness, Inner Door	5	W11091934	Latch Assembly (Includes Switch)
	W11549246	Black	3	W10941960	Screw	6	W11690648	Inner Door Assembly (Includes Soap Dispenser)
	W11549245	White	4	W10711884	Screw			


# TUB AND FRAME PARTS



# TUB AND FRAME PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Tub (Not Serviced)	17	W11317036	Cover, Top	31	W11227934	Cap, Salt
2	W11671752	Pad, Tub Support	18	W11306174	Crossbar, Front Frame	32	W11546882	Softener, Water
3	W11658880	Gasket, Tub	19	W11355600	Side Panel (Left)	33	W11224085	Seal, Softener
4	W11236521	Nut, Air Break		W11355598	Side Panel (Right)	34	W11509486	Funnel, Salt
5	W11314779	Strike, Latch	20	W10986499	Screw	35	W11686061	Plate, In/Out Hoses
6	W11316238	Assembly, Leveling Leg (Rear)	21	W11690567	Assembly, Base	36	W11545951	Jumper, RFI to Control
7	W11554391	Retainer, Tub Gasket	22	W11564606	Shield, Tub Sound	37	W10943118	Spring, Grounding
8	W11325471	Rod, Foot Adjustment (Rear)	23	W11643567	Assembly, Junction Box	38	W11578108	Power Cord Assembly
9	W11668893	Holder, Damper	24	W11696038	Miscellaneous Parts Bag	39	W11418782	Filter, RFI
10	W11317043	Cover, Door Opening	25	W11525808	Spacer, Side Panel	40	W11646878	Jumper Harness, Service Port
11	W11590760	Assembly, Door Opening	26	W11350847	Screw	41	W11696402	Control, Electronic
12	W11316692	Cover, Tub Corner (Left)	27	W10941972	Screw	42	W11609315	Wiring Harness, Main
	W11316688	Cover, Tub Corner (Right)	28	W11345595	Tub Mount, Upper Rack	43	W11684708	Channel, Overflow (Left)
13	W11602936	Float Switch	29	W11386114	Tub Mount, Third Level Rack (Left)		W11684709	Channel, Overflow (Right)
14	W11321022	Plug, Tub		W11386113	Tub Mount, Third Level Rack (Right)	44	W11630670	Nut, Tub
15	W11568183	Air Break	30	W11227921	Nut, Softner	45	W11673775	Kit, Side Cover Installation
16	W11325130	Leg, Leveling (Front)				46	W11656505	Button, Tub

# PUMP, WASHARM AND MOTOR PARTS






# PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11630727	Heater, Pump	9	W10096851	Clamp, Hose	18	W11008964	Hose, Inlet
2	W11630725	Motor, Pump	10	W11631981	Motor, Drain	19	W11445183	Grate
3	W11560668	Sump (includes Seal and Diverter)	11	W11586395	Hose, Drain	20	W11543924	Diverter Valve Motor
4	W11559823	Drain Vent Assembly	12	W11175586	Disc, Diverter	21	W11559846	Filter
5	W11560657	Diffuser, Inlet	13	W11545826	Fill Valve Assembly			
6	W11560834	Check Valve, Drain	14	W11122851	Clamp, Hose			
7	W11528067	Wash Arm Assembly	15	W11457583	Hose, Inlet			
8	W11008962	Hose, Pump Inlet	16	W11126174	Indicator, Optical Wash			
			17	W11626817	Clip, Hose			


# UPPER WASH AND RINSE PARTS



# UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11668593	Feed Tube Assembly	3	W11522201	Sprayarm, Third Level	4	W11392059	Upper Sprayarm Assembly
2	W11522213	Retainer, Docking (2nd Level)				5	W11602500	Cover, Diverter


# UPPER RACK AND TRACK PARTS



# UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11521613	Dishrack, Upper	5	W11562047	Adjustment Assembly (Left)	6	W11356045	Support, Tine Row
2	W11315114	Track Stop, Front				7	W11592682	Clip, Cup Shelf
3	W11315116	Track Stop, Rear		W11562045	Adjustment Assembly (Right)	8	W11592896	Cup Shelf
4	W10884045	Track, Dishrack				9	W11538488	Tine Row, Fold Down


# LOWER RACK PARTS



# LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11543671	Dishrack, Lower	3	W11629678	Silverware Basket Assembly	4	W11634637	Utensil Basket (Rear)
2	W11543733	Wheel & Transport Assembly				5	W11634635	Utensil Basket (Front)

# THIRD LEVEL RACK AND TRACK PARTS





# THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11603517	Rack, Third Level	3	W11315114	Track Stop, Front
2	W10884045	Track, Dishrack	4	W11315116	Track Stop, Rear