




## **GAS RANGE**

### **MODELS:**

WFGS3530RB0 (Black)

WFGS3530RW0 (White)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	4		Cooktop	10	W11379945	Bracket, Anti-Tip
	W11624706	Owner's Manual		W11331143	Black	11	7101P485-60	Screw, Anti-Tip Kit
	W11627309	Tech Sheet		W11331141	White	12	W10465081	Grate, Bumper
	W11624074	Quick Start Guide	5		Panel, Manifold			FOLLOWING PARTS NOT ILLUSTRATED
2		Burner Cap Kit		W11089575	Black		W11393744	Harness, Main
	W11395131	Black (Set of 4)		W11089574	White		W11448086	Harness, Bake and Broil
3	W11352018	Spreader, Flame (Left Front and Right Front)	6		Knob, Control		313438	Clip, Harness
	W11352020	Spreader, Flame (Left Rear)		W11510457	Black		3196173	Screw
	W11352021	Spreader, Flame (Right Rear)		W11510458	White		3196520	Clip, Wire
			7		Kit, Grate (Set of 2)		3196896	Clip, Wire
				W11603169	Grates, Cooktop			
			8	W10673618	Screw			
			9	3196557	Screw			


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap	6	W10516123	Bracket, Console Mounting	14	W11290750	Bracket, Control
	W11213290	Black (Left)				15	W10797001	Bracket, Ignitor
	W11213292	Black (Right)	7	8523412	Bracket, Rear Cooktop	16	W10110488	Module, Spark
	W11213291	White (Left)	8	W10198745	Cover, Upper	17	3196165	Screw
	W11213293	White (Right)	9	W10192841	Shield, Heat	18		Bracket, Eye Brow
2	8053505	Shield, Heat	10	W11676199	Cover, Back		W11443964	Black
3		Panel, Control	11	3196169	Screw		W11443963	White
	W11385177	Black	12		Control, Range (LCC190)			
	W11385178	White						
4	W10762981	Bracket, Mounting		W11637091	Black			
5	W10818365	Module, Spark	13	3196178	Screw			


# CHASSIS PARTS



# CHASSIS PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11457094	Box, Flue	16	W10390008	Base Rail Assembly (Left)	29	W10571723	Bulb, Halogen 40 Watts
2	8272747	Shield, Flue						
3	W11379351	Box-Burner, Gas Sealed		W10390007	Base Rail Assembly (Right)	30	9761013	Front Door Latch Assembly
4		Panel, Side	17	9757239	Rod, Door Switch	31	W10078370	Rod, Push Latch
	W10162245	Black	18	W10031780	Screw	32	W10107820	Rear Door Latch Assembly
	W10575396	White	19	3400080	Screw	33	W10674705	Glide, Drawer Front
5	W10137382	Clip, Panel	20	W11173792	Rack, Oven	34	3196178	Screw
6	8523249	Bracket, Manifold	21	W11491751	Seal, Door	35	W10379120	Screw
7	W10362924	Screw	22	W10435470	Brace, Main Back	36	W11464547	Bracket, Front Frame
8	3196560	Screw	23	W11379353	Retainer, Insulation (Left)			FOLLOWING PARTS NOT ILLUSTRATED
9	W10341186	Front Foot Assembly		W11379943	Retainer, Insulation (Right)			
10	W10058460	Foot, Leveling					8524099	Insulation, Wrap
11	3195097	Bottom, Oven	24	3196560	Screw		W11697359	Insulation, Back
12	W10586204	Sensor	25	W11661976	Cord, Power		W10333344	Insulation, Flue
13	8053967	Baffle, Burner Oven	26	W10289077	Receiver, Hinge			
14	8053969	Shield, Heat	27	W11511828	Switch, Door			
15	W11640074	Shield, Lower	28	W11634772	Light Assembly			

# MANIFOLD PARTS






# MANIFOLD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	8	W11509685	Valve, Gas (Left Front and Right Front)	18	W10827923	Electrode, Spring
2	W10949105	Bracket, Saddle Valve				19	W11485872	Orifice (15K) (Left Front)
3	W11459257	Orifice Holder Assembly (15K)  (Left Front)		W11509686	Valve, Gas (Left Rear)		W11485873	Orifice (9.5K) (Left Rear)
	W11459258	Orifice Holder Assembly (9.5K)  (Left Rear)		W11509687	Valve, Gas (Right Rear)		W11428753	Orifice (15K) (Right Front)
	W11459260	Orifice Holder Assembly (15K)  (Right Front)	9	W10224921	Bracket, Aegis		W11485871	Orifice (5K) (Right Rear)
	W11459259	Orifice Holder Assembly (5K)  (Right Rear)	10	3196385	Screw	20	W10362924	Screw
4	W10215439	Tubing (Manifold to Regulator)	11	3400016	Screw	21	3196265	Screw
5	W11537750	Harness, Switch	12	W10714060	Element, Broiler			FOLLOWING PARTS NOT ILLUSTRATED
6	W11450459	Electrode, Bake	13	W10184491	Spreader, Flame (Oven)		W11489400	LP Conversion Kit
7	W11510001	Manifold Assembly	14	9758078	Burner, Bake		W10838304	Orifice, LP Bake
			15	W11620067	Regulator			
			16	W11428831	Electrode  (Left Front and Left Rear)			
				W11428858	Electrode  (Right Front and Right Rear)			
			17	W10182767	Tie, Manifold Wire			

# DOOR PARTS




# DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle and Vent Assembly
	W11353052	Black
	W11353053	White
2		Trim, Lower
	W11444043	Black
	W11444042	White
3	W10031780	Screw
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner
7	W10316950	Frame, Glass

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10278991	Insulation, Door Strip
9	W11380222	Retainer, Insulation
10	W10388635	Hinge, Door (Active)
11		Glass, Outer Door
	W11624777	Black
	W11624778	White
12		Trim, Door
	W10746436	Black (Left)
	W10746435	Black (Right)
	8523172	White (Left)
	8523166	White (Right)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10327235	Screw
14	W11379944	Strap, Door
15	W10440013	Hinge, Door (Active)
16	W10884775	Badge
17	W10200660	Screw
18	W10465158	Screw

# DRAWER PARTS



# DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front	3	W10462911	Bracket, Mounting	6		Rivet, Push
	W11123976	Black	4	W10674708	Glide, Drawer Rear		3196813	Black
	W11123977	White	5	3196169	Screw		3196814	White
2	W10688022	Drawer, Storage						

# OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		FOLLOWING PARTS NOT ILLUSTRATED
		REFINISHING MATERIAL
	242756	Oven Liner Touch Up Paint
		INSULATION
	261514	Insulation (1-1/2 x 24 x 120 in)
	240132	Insulation (2-1/2 x 22 x 120 in)
		PAINT, TOUCH-UP (1/2oz.)
	4392899	Biscuit and Bisque
	72017	White
	511873	White Porcelain (2 oz.)
		PAINT, PRESSURIZED SPRAY (12 oz.)
	285006	Black
	350930	White
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
		ACCESSORY PARTS
	W10355016	Cleaner, Stainless Steel
	4396096RB	Griddle
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan and Roasting
	W10539770	Wipes, Cleaning
	W10275756	Cleaner, Granite