




## Dishwasher

### MODELS:

WDP560HAMB0 (Black)  
WDP560HAMW0 (White)  
WDP560HAMZ0 (Stainless)


# DOOR AND PANEL PARTS



# DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel (Includes Hardware)	13	W10519755	Insulation, Toe Panel
	W11612297	Energy Guide				14		Access Panel & Insulation Assy
	W11532445	Owners Manual		W10441006	Black		W10369023	Black
	W11532444	Tech Sheet		W10441007	White		W10369025	White
2		Arm, Hinge	6		Fastener	15	W10711884	Screw
	W11484017	Left Hand		W10503548	Black			
	W11484018	Right Hand		W10503549	White			
3	W10803537	Stiffener, Door	7	8268961	Sleeve, Friction			
4		Panel, Front (Includes 8 & 9)	8	W10692757	Barrel Nut, Front Panel			
	W11528191	Black	9	W11504190	Light, Pipe			
	W11528189	White	10	3400071	Screw			
	W11528192	Stainless	11	W10315897	Insulation, Front Panel			
			12	9741232	Screw			


# CONTROL PANEL AND LATCH PARTS



# CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	3	W10825369	Brace, Connector	6	W10653840	Latch Assembly (Includes Switch)
	W11504635	Black	4	W11557319	Control, Electronic			
	W11504636	White	5	W11096645	Screw	7	W10177098	Screw
2	W10825638	Box, Connector						


# INNER DOOR PARTS



# INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw	4	W10920683	Door Bottom, Seal	7	W11531479	Deflector, Vent
2	W11050927	Seal, Console/Door	5	W11527847	Vent Assembly	8	W10620296	Dispenser Assembly
3	W11631034	Inner Door Assembly	6	W11476843	Screw	9	W11515203	Wiring Harness
						10	W11184028	Gasket, Vent

# FILL, DRAIN AND OVERFILL PARTS





# FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	10	304231	Screw
2	W10769066	Inlet Hose	7	W11130744	Fill Valve Assembly	11	W10195039	Switch, Overfill Control
3	W10195536	Inlet, Water (Also Order Item 4)	8	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	12	W10316267	Standpipe, Overfill
4	8531323	Gasket				13	W10346525	Float & Retainer Assembly
5	W10508676	Nut, Inlet (Also Order Item 4)	9	W10545278	Drain loop with check valve assembly	14	W10195037	Lever, Overfill Switch




# TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10908439	Tub Assembly	12	8268991	Cover, Terminal Box	21	W10732961	Bracket, Heater Support
2	W11521240	Shield, Thermostat	13	W10866979	Shield, Tub Sound	22	W10441445	Heater Element Assembly
3	W11425053	Seal, Tub	14	W10539489	Clip, Thermostat			(Includes Heater Washer & Nut)
4	W10341745	Screw	15	3371618	Thermostat			
5	W11296374	Screw	16	W10544004	Strike, Latch			
6	8269145	Bracket, Undercounter	17	3378128	Washer, Pronged Cup			
7	W10304231	Support, Bottom	18	3400014	Screw, Grounding			
8	W10619352	Leveler, Leg	19	W10819539	Sound Insulation, Bottom			
9	W10337934	Spring, Door Balance	20	8268990	Bushing, Door Spring	23	W10277003	Screw
10	489470	Screw						
11	3400892	Screw						

NOTE: If heater element is removed, it must be replaced.


# PUMP, WASHARM AND MOTOR PARTS



# PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	6	W10372113	Tab, Sump	13	8269146	Clamp, Hose
2	W10482462	Sump With Seal (Also Order Items 12 & 16)	7	W10789806	Filter Cup Assembly	14	W10195086	Motor, Isolator
3	W10463906	Screen	8	W10724439	Pump, Drain	15	W11521435	Motor (Also Order Items 12 & 16)
4	W10348407	Screw	9	8269144	Hose, Drain			
5	W11525546	Sump & Motor Assembly	10	370445	Clamp, Hose	16	W10445975	Hose Assembly (Includes 2 Clamps)
			11	W11525024	Sensor, Temperature	17	W10491331	Sprayarm
			12	W11182008	Grommet			


# UPPER WASH AND RINSE PARTS



# UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11540183	Feed Tube Assembly	4	W10340542	Manifold
2	W10165274	Screw	5	W10328508	Feed Tube Retainer
3	W10448645	Sprayarm			

# UPPER RACK AND TRACK PARTS






# UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10350382	Dishrack, Upper	6	W10508950	Stop, Track (Removable)	11		Housing, Adjuster
2	W10195840	Positioner, Adjuster					W10195372	Left Hand
3	3385089	Track, Dishrack	7	3379676	Wheel		W10195373	Right Hand
4	W10082860	Stop, Track (Non-Removable)	8	W10082649	Cupshelf Assembly	12	W10250160	Clip, Adjuster
5	W10195839	Strap, Tether Adjuster	9	W10082848	Clip, Cupshelf	13	W10250162	Cover, Adjuster
			10	W10350375	Adjuster, Arm Assembly			

# LOWER RACK PARTS



# LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300732	Dishrack, Lower	3	W11550304	Silverware Basket Assembly	4	W10179398	Silverware, Basket
2	W10082868	Wheel & Transport Assembly				5	W10193647	Lid, Side

# OPTIONAL PARTS (NOT INCLUDED)

## ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft. Handle Assembly
	W10702080	Black
	W10702081	White

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit and Bisque

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit and Bisque

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	4392900	Biscuit/Bisque

## POWER CORD KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

## ANTI-TIP KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

## DISHRACK REPAIR

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis