




REFRIGERATOR

MODELS:

WRMF3636RV00 (Black Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	14	12992403	Screw	28	688983	Screw
	W11665549	Tech Sheet	15		Hinge, Center	29	W10914798	Gasket, Control Box
	W11608713	Owners Manual		W11610757	Left Hand	30	W10270394	Cover, Unit
	W11730573	Energy Guide	16		Hinge, Center	31	W10141622	Brake, Roller
2	W11232485	Tube, Water		W11610758	Right Hand	32	W10367522	Slide, Mullion Vent
3	12698403	Plate, Pivot	17		Cover, Corner	33		Assembly, Roller
4	W11534848	Gasket		12587703B	Black		W10515763	Left Hand
5		Cover, Top Hinge	18	W10827867	Knob, Vent Slide		W10515762	Right Hand
		Left Hand	19		Cover, Fill Tube	34		Assembly, Secondary Mullion
	W10337647	Black		12981401B	Black		W11717550	Black
6		Cover, Top Hinge	20	W10709365	Screw	35	W11228040	Assembly, LED Light Module
		Right Hand	21		Shim, Top Hinge			
	12962302B	Black		12999501	Left Hand			
7	12961602	Cover, Control Box		12999502	Right Hand	36	W10820998	Housing, Module
8	M0108107	Clamp, Tube	22		Grille, Toe	37	W10492234	Brace, Mullion
9	12992602	Screw		W10534153	Black	38	W11097348	Mullion, Secondary
10		Hinge, Top	23	W10296541	Lid, HV Control Box	39	W11651067	Block, Fill Tube
	W11456626	Left Hand	24	W11651065	Wedge, Spacer (Left Hand & Right Hand)			
	W11456625	Right Hand						
11	W10673840	Screw (Stainless)	25	12990702	Screw			
12	12990511	Screw	26		Cabinet (Not A Servicable Part)			
13	W11651073	Wedge, Spacer (Left Hand & Right Hand)	27	W11321365	Control, Electronic			


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	5	W10555984	Assembly, Air Grille	11	W11513126	Cover, Upper Water Tank
2	W11387579	Assembly, Upper Light (Includes LED Module and Lens)	6	W10847849	Switch, Light	12	W11510661	Cover, Filter
			7	W10309869	Cover, Wiring	13	W11565236	Cover, Lower Water Tank
			8	W11446814	Valve, Water Inlet			
3	W11519216	Assembly, Water Tank and Manifold	9	W10334463	Bracket, Water Tank and Valve	14	W11536439	Filter, Water
4	W11510659	Bracket, Filter Base	10	W11518277	Tube, Water			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	12	12990511	Screw	21		Adapter Assy-FC.Slide
2	A3189392	Gasket, Foam	13		Bracket, Door Slide		W10284682	Left Hand
3	12002497	Gear		W10330991	Left Hand		W10284683	Right Hand
4	12990501	Screw		W10330993	Right Hand	22	12959901	Grille, Air
5	W10802332	Shaft, Rack	14	W11328652	Module, Light	23	12951401	Shroud, Evaporator
6	M0500703	Seal	15	12956601	Clip, Fan Motor	24	12986101	Blade, Fan
7	12815301	Cover, Thermistor	16	W11385734	Switch, Light	25	W10905511	Grommet, Fan Motor
8	12990521	Screw	17	12990504	Screw	26	W11314192	Motor, Evaporator (Includes Heater Harness and Defrost Thermostat)
9	W11468934	Light Module, LED	18	B8381501	Gasket, Drain			
10	12791417SP	Thermistor	19	W11644400	Slide, Door			
11	W10308421	Cover, Evaporator	20	A3189396	Gasket	27	W10662407	Assembly, Drain Funnel


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	9		Handle, Door	17		Latch, Door Closer
		Left Hand		W10918272	Black Stainless			Right Hand
	W11022747	Black Stainless	10	W10884773	Badge		W10725267	Black
2		Door, Refrigerator	11	W11431179	Waterline, Door	18		Latch, Door Closer
		Right Hand	12	W10287601	Seal, Ice Chute			Left Hand
	W11022757	Black Stainless	13		Mullion, Door		W10725268	Black
3	W11698402	Bucket, Small	14		Closure, Door	19	W11698403	Bucket, LH Upper
4	12990521	Screw		12028505B	Black	20	12990518	Screw
5	W11698404	Bucket, Gallon	15		Stop, Door			
6	12990204	Screw		12968202B	Black			
7	W11328753	Screw	16	12996601	Clip, Bushing			
8		Gasket, Door						
	W10830274	Grey						


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer	8		Rack, Side	11		Handle, Door
	W10920749	Black Stainless		W11309374	Left Hand		W11101977	Black Stainless
2		Gasket, Door		W11309377	Right Hand	12	W11328753	Screw
	W10714545	Grey	9		Mount, Gear			
3	W10293682	Bin, Lower		W10348259	Left Hand			
4	W10802333	Shaft, Rack		W10348260	Right Hand			
5	W11115237	Basket, Upper	10		Bracket, Door Slide			
6	W10146439	Divider, Upper Basket		W10330991	Left Hand			
7		Gear		W10330993	Right Hand			
	W10474716	Left Hand						
	W10474715	Right Hand						


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	19	W10281329	Clip, Drier	28	W11563970	Compressor
2	12825803	Blade, Fan	20	W11337767	Tray, Drip			(Also Order the Following Lokring™ Parts)
3	W11604794	Basepan	21	W10303521	Sleeve			
4	12990511	Screw	22	W11337423	Evaporator			
5	2319835	Grommet, Condenser			(Also Order the Following Lokring™ Parts)		W11504416	8.5/6 NR MS 00 (Suction Tube to Compressor)
6	W11623085	Tube, Suction					W11504431	7/5 NR MS 00 (Discharge Tube to Compressor)
7	2169104	Insulation, Sound Deadening		W11504423	8/2 NR AL 00 (Capillary Tube to Evaporator)			
8	W10655368	Pan, Drain					W11506621	6 NK MS 00 (Charging Tube to Compressor)
9	W10622701	Screw		W11504415	8.5/8 NR MS 00 (Suction Line to Evaporator)			
10	W11287565	Heater, Defrost						
11	W11359985	Device, Start						
12	W11629200	Strap, Bale	23	W11244122	Gasket, Foam		W11506635	Tube, Charging (1/4 in w/ Schrader Valve)
13	W10137529	Grommet, Condenser	24	W11505534	Motor, Condenser Fan			
14	W10622099	Extension, Drain Tube	25	W11380964	Clip, Heater	29	10623002	Clip, Evaporator
15	12477102	Roller	26	W11654037	Harness, Unit (Includes Power Cord)	30	12477202	Axle, Roller
16	12992101	Screw				31	W11463236	Shroud, Condenser Fan
17	W11631702	Grommet	27	W10805035	Drier (Service Drier Without Dye)			
18	W11597885	Condenser			(Also Order the Following Lokring™ Parts)	32	W10350564	Capacitor
		(Also Order the Following Lokring™ Parts)				33	W10236396	Strap, Compressor
	W11506623	5 NK MS 00 (Discharge Tube to Condenser)		W11504445	5/4 NR MS 00 (Heat Loop to Drier)	34	W10815863	Clip, Condenser
	W11504432	6/5 NR MS 00 (Heat Loop to Condenser)		W11504447	5/1.8 NR MS 00 (Capillary Tube to Drier)	35	W11309682	Harness, Evaporator Heater (Includes Defrost Thermostat)
								REFRIGERANT CHARGE 51 grams (R600a)


SHELF PARTS



SHELF PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11694315	Glass, Pan Cover	13	W10272364	Screw	27		Cover, Pantry Rail
2	W10331298	Rail, Rear Pantry	14	W11328753	Screw		W10311725	Left Hand
3	12990521	Screw	15	W10802341	Shaft, Rack	28		Adapter, Side
4	W11694348	Pan Assembly, Crisper	16		Ladder, Side		W11702389	Left Hand
5	W11606482	Roller Assembly, Crisper		W10251968	Left Hand	29		Adapter, Side
6	W11697425	Shelf, Mini		W10251965	Right Hand		W11702392	Right Hand
7		Door, Pantry	17	W10277361	Collar, Gear	30	W10840918	Flange, Side Support
	W10920753	Black Stainless	18	W11340451	Pan, Pantry	31	W10804977	Screw
8		Gasket, Pantry	19	W10273464	Ladder, Center	32	W10840922	Knob, Side Support
	W10443326	Grey	20		Handle, Door	33	W11702378	Assembly, Pan Center Support
9	W11697422	Shelf, Stationary		W11101977	Black Stainless	34	W11705308	Support, Crisper Frame
10		Adapter, Pantry	21	12990513	Screw	35	W11700717	Brace, Crisper Support
	W11093713	Left Hand	22	12990512	Screw			
	W11093714	Right Hand	23	W11340457	Divider, Pantry			
11	W10277360	Gear, Spur	24	W10296571	Glass, Pantry Shelf			
12		Cover, Gear	25	W10847852	Switch, Rocker			
	W10284709	Left Hand	26		Rail, Pantry			
	W10294414	Right Hand		W10311723	Left Hand			
				W10311726	Right Hand			


DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	5	W10238083	Assembly, LED	10		Tray, Dispenser Slide
2		Assembly, User Interface	6	W10353552	Assembly, Separator (Includes Spigot and Ice Guide)		W11045966	Black Stainless
	W11600493	Stainless	7	2316647	Assembly, Spigot Body	11	W10254277	Cover, Board
3		Wall, Dispenser False	8	W10339578	Guide, Ice	12	W10205979	Motor, Ice Door
	W11045979	Graphite	9		Dispenser, Tray	13	489214	Screw
4		Assembly, Pad (Includes Blue Light)		W11045974	Graphite			
	W10353847	Black						

ICEMAKER & ICE CONTAINER PARTS



ICEMAKER & ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11097357	Assembly, Ice Bin	10	W10884561	Motor, Dispenser	19	W11525256	Assembly, Complete Icemaker
2	W10121282	Inlet, Blower	11	W10196393	Damper, Control	20	12791417SP	Thermistor
3	W10309863	Scroll, Blower	12	W11182941	Assembly, Solenoid	21	W11309962	Harness, Icemaker
4	W11299369	Motor, Fan	13	W10118612	Liner, Divider			
5	W10123444	Wheel, Blower	14	12990511	Screw			
6	12956603	Clip, Fan Motor	15	W10346971	Bracket, Solenoid			
7	W10151687	Grommet, Fan Motor	16	W10465946	Washer			
8	W10309864	Divider, Ice Box	17	63052A001	Yoke, Ice Dispenser			
9	12920001	Gasket, Damper	18	W11323371	Assembly, Impinger			

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TOUCH-UP PAINT
	72032	Black PAINT, PRESSURIZED SPRAY (12 oz.)
	350939	Enamel, Black
	285006	Black Important: The spray paint is not to be used where the paint may make contact with the door gaskets.
		MISCELLANEOUS
	212643	Sealer, Gum (4 Feet)
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet