




REFRIGERATOR

MODELS:

WRQC7836RZ00 (Stainless)


CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W11088974	Jumper Wire Assembly, Hinge Cover Switches	13	W11351740	Bottom Hinge and Leveler Assembly (Left Hand)
	W11689442	Owners Manual						
	W11712181	Tech Sheet	8	W11171145	Sensor, External Humidity	14	W11351739	Bottom Hinge and Leveler Assembly (Right Hand)
2		Cabinet (Not a Serviceable Part)	9	W11306512	Pivot Block, Mullion			
3	W11314383	Cover, Hinge	10	W11083859	Cover, Screw			
4	W11097769	Top Hinge (Left Hand)	11	W11334827	Center Hinge (Left Hand)			
5	W11097767	Top Hinge (Right Hand)	12	W11334651	Center Hinge (Right Hand)			
6	W11115055	Switch, Reed						







SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11674178	Tuck Shelf Assembly	4	W11727445	Frame Assembly, Refrigerator Drawers	6	W11727452	Pantry Pan Assembly
2	W11727442	Full Shelf Assembly	5	W11674179	Crisper Pan Assembly	7	W11293351	Door, Filter
3	W11129025	Glass, Crisper Cover						


FREEZER DRAWER PARTS



FREEZER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11688904	Pullout Tray Assembly	5	W11675455	Bottom, Drawer Assembly	8	W11293494	Adapter Plate Assembly, Bottom (Right Hand)
2	W11675457	Drawer Assembly, Middle (Fast Freeze)	6	W11293508	Adapter Plate Assembly, Top (Right Hand)	9	W11293496	Adapter Plate Assembly, Bottom (Left Hand)
3	W11675459	Drawer Assembly, Middle (Freezer-To-Fridge)	7	W11293510	Assembly, Adapter Plate (Left Hand)			
4	W11675453	Drawer Assembly, Bottom (Fast Freeze)						


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	W11186092	Fan, Evaporator	12	W11298026	Thermistor, Evaporator Defrost
2	W11320419	Light Strip, LED	8	W11049305	Rear Cover, Evaporator Fan	13	W11389906	Heater, Defrost
3	W11727741	Air Tower Assembly	9	W11171146	Sensor, Internal Humidity	14	W11294151	Shelf Support (Front Left/Rear Right)
4	W11135456	Thermistor, Temperature	10	W11093285	Evaporator Cover Assembly, Refrigerator	15	W11294153	Shelf Support (Front Right/Rear Left)
5	W11083859	Cover, Screw	11	W10920204	Evaporator, Refrigerator			
6	W11049306	Front Cover, Evaporator Fan						

FREEZER LINER PARTS




FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	W11389905	Heater, Defrost	12	W10909729	Evaporator, Convertible Compartment
2	W11174204	LED Module	9	W11320020	Evaporator Cover Assembly, Freezer	13	W11384547	Evaporator Cover Assembly, Convertible Compartment
3	W11091630	Bracket, Ice Box Fan	10	W11135456	Thermistor, Temperature			
4	W11251035	Seal, Ice Box Fan	11	W11186092	Fan, Evaporator			
5	W11284795	Fan, Ice Box						
6	W11091622	Evaporator, Freezer						
7	W11298026	Thermistor, Evaporator Defrost						

REFRIGERATOR DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11735094	Door, Refrigerator Left Hand	9	W11357426	Shaft, Dispenser Motor	18	W11334421	Bin, Medium Door
2	W11733389	Door, Refrigerator Right Hand	10	W11391787	Dispenser Motor	19	W11636290	Bin, Gallon Door
3	W11171965	Badge	11	W11110857	Stopper, Door	20	W11334420	Bin, Stadium Door
4	W11205537	Mullion, Door	12	W11306079	Latch, Door Closer (Right Hand)	21	W11292783	Clip, Supply Duct Gasket
5	W11376604	Gasket, Refrigerator Door	13	W11306401	Latch, Door Closer (Left Hand)	22	W11292786	Gasket, Return Duct
6	W11032814	Switch, Rocker Arm	14	W11361142	Ice Maker Assembly	23	W11292789	Clip, Return Duct Gasket
7	W11728172	Door Assembly, Ice Compartment	15	W11316215	Ice Bin Assembly	24	W11297729	Gasket, Supply Duct
8	W11312187	Plate, Ice Chute	16	W11130119	Coupling, Auger	25	W11024885	Magnet, Switch
			17	W11334422	Trivet, Ice Compartment Door			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11733588	Door, Freezer Right Hand	5	W11024885	Magnet, Switch	9	W11306327	Gasket, Freezer Door
2	W11733594	Door, Freezer Left Hand	6	W11110857	Stopper, Door	10	W11334423	Bin, Freezer Door
3	W11306508	Seal, Vertical	7	W11306079	Latch, Door Closer (Right Hand)	11	W11334424	Bin, Tall Freezer Door
4	W11306510	Seal, Horizontal	8	W11306401	Latch, Door Closer (Left Hand)			


DISPENSER PARTS



DISPENSER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11727995	User Interface	3	W11675938	Housing Assembly, Dispenser (Includes Switches)	4	W11413960	Grate, Drip Tray
2	W11310097	Motor and Bracket Assembly, Ice Door				5	W11413956	Drip Tray


WATER SYSTEM PARTS



WATER SYSTEM PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11628207	Tube, Water (Valve to Hinge, Ice Maker)	4	W11125031	Housing, Water Filter	8	W11293052	Cover, Water Valve
2	W11628075	Tube, Water (Valve to Hinge, Dispenser)	5	W11166019	Heater, Water Filter	9	W10680605	Filter, Water
3	W11451854	Water Box Assembly	6	W11167973	Valve Assembly, Dual Water	10	W11332416	Cap, Water Filter
			7	W11083973	Reservoir, Water	11	W11432232	Valve, Water Inlet
						12	W11135271	Guard, Water Valve

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11700395	Control Board	9	W11037729	Fan, Condenser	17	W11039081	Cover, Machine Compartment
2	W11029002	Lid, Main PCB	10	W11165514	Condenser	18	W11368461	Cord, Power
3	W11385399	Line Filter	11	W11304825	Bracket, Condenser			REFRIGERANT CHARGE
4	W11728019	Suction Tube	12	W11093946	Drain Tube			59 grams (R600a)
5	W10805035	Drier (Service Drier Without Dye)	13	W11327053	Drain Tube			
6	W11675958	Compressor Assembly	14	W11305915	Drain Pan			
7	W11675965	Inverter	15	W11027541	Plate, Compressor Base			
8	W11245686	Valve Assembly, 4-Way Refrigerant	16	W11083695	Cover, Compressor Roller			